

COP 1838 Drifter Parts for Atlas Copco

Atlas Copco

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
			ROCK DRILL	COP 1838			
1A		COP 1838	-	extractor unit (mex/hex)			
1B		COP 1838	-	front head (me/he/hf)			
2		COP 1838	3115 0286 00	dome nut		O	0.26kg
3		COP 1838	3115 0287 00	washer		O	0.04kg
4		COP 1838	3115 1457 00	side bolt		O	0.82kg
5		COP 1838	3115 2113 00	side bolt		O	1.34kg
		COP 1838	3115 2949 80	cover, compl		O	
6		COP 1838	-	-cover			
7		COP 1838	0666 7190 01	-seal ring		O	0.06kg
8		COP 1838	0335 2173 00	-lock ring		O	0.04kg
9		COP 1838	0102 0473 00	cylindrical pin		O	
10		COP 1838	0663 2101 66	o-ring			
11		COP 1838	3115 0297 01	shim, 0.10mm		O	0.01kg
11		COP 1838	3115 0297 02	shim, 0.15mm		O	0.03kg
11		COP 1838	3115 0297 03	shim, 0.5mm		O	0.1kg
12		COP 1838	0509 0223 00	roller bearing 32018XQ		O	1.8kg
13		COP 1838	3115 1582 00	driver		O	1.66kg
		COP 1838	3115 1732 81	rotation chuck, compl		O	4.44kg
14		COP 1838	-	-rotation chuck			
15		COP 1838	3115 1881 00	-bushing		O	0.18kg
16		COP 1838	0509 0221 00	roller bearing 32016XQ		O	1.3kg
		COP 1838	3115 2340 80	gear housing, compl		O	
17		COP 1838	3115 2340 00	-gear housing		O	
18		COP 1838	0686 4201 03	-plug		O	
19		COP 1838	0653 9038 00	-gasket		O	
20		COP 1838	0544 2162 00	-lubricating nipple		O	
21		COP 1838	0666 7188 01	-seal ring		O	0.04
22		COP 1838	0335 2169 00	-lock ring		O	0.06
23		COP 1838	3115 0273 00	-washer		O	0.02
24		COP 1838	0663 2120 00	o-ring			
25		COP 1838	3115 2064 00	rotation chuck bushing		O	1.38kg
		COP 1838	3115 0821 80	shaft, compl		O	2.14kg / 27,29,30,31,26,32 set
26		COP 1838	3115 0821 00	-shaft		O	1.54kg
27		COP 1838	0516 1504 01	-needle bearing		O	0.06kg
28		COP 1838	3115 0823 00	-washer		O	0.02kg
29		COP 1838	0516 1538 00	-needle bearing		O	0.1kg
30		COP 1838	3115 0824 00	-sleeve		O	0.2kg
31		COP 1838	0667 1206 00	-cup seal		O	
32		COP 1838	3115 2742 00	-guide sleeve		O	0.3kg
33		COP 1838	3115 0274 00	gear		O	0.64kg
34		COP 1838	0663 2133 01	o-ring			

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
35		COP 1838	3115 2382 00	damping piston		O	2.92KG
			3115 2583 45	intemediate part, compl		O	Manufacturing
		COP 1838	3115 2583 81	intemediate part, compl		O	3115 2583 10 / 3115 2381 81
36		COP 1838	-	-intemediate part			
		COP 1838	0259 2061 00	--thread insert			
37		COP 1838	3115 1746 06	--nozzle (1.7mm)		O	
39		COP 1838	0686 6442 00	--plug	1	O	0.02
40		COP 1838	0661 1020 00	--seal washer		O	
41		COP 1838	3115 2670 00	-liner		O	1.16
42		COP 1838	0663 2104 94	-o-ring			
43		COP 1838	0663 2105 96	-o-ring		O	
44		COP 1838	0335 3500 10	-lock ring		O	
45		COP 1838	3115 2084 00	-bushing		O	0.08kg
37		COP 1838	3115 1746 06	-nozzle (1.7mm)		O	
46		COP 1838	-	set of seals		O	0.06
47		COP 1838	-	set of seals		O	0.06
48		COP 1838	3115 2884 00	connection plate (me/mex/hf)		O	3115 3455 00
48		COP 1838	3115 2114 00	connection plate (he/hex)		O	
49		COP 1838	0211 1960 84	screw		O	
50		COP 1838	0663 2100 62	o-ring			
51		COP 1838	0686 9110 00	protective plug			
52		COP 1838	3115 2696 80	diaphragm accumulator		O	4.04KG / 3115 3511 81
52		COP 1838	3115 2900 80	intake accumulator compl (he/hex)		O	7.44kg / 3115 2391 81[Old]
		COP 1838	3115 2766 80	seal housing, compl (he/hex)		O	0.40kg
53		COP 1838	-	-seal housing			
54		COP 1838	3115 0970 00	-set of seals		O	
55		COP 1838	0663 6136 00	-o-ring			
56		COP 1838	0663 6143 00	o-ring			
57		COP 1838	3115 1671 00	piston guide, front		O	0.28KG / 3115 5050 01
58		COP 1838	0663 6134 01	o-ring			
59		COP 1838	3115 1765 00	valve piston		O	0.38kg
60		COP 1838	3115 2077 03	valve cover, left (me/mex/he/hex)		O	
60		COP 1838	3115 2077 05	valve cover, left (hf)		O	
61		COP 1838	3115 2076 05	valve cover, right (me/mex/he/hex)		O	
61		COP 1838	3115 2076 03	valve cover, right (hf)		O	
62		COP 1838	0147 1438 03	screw		O	0.06
63		COP 1838	3115 2115 02	regulating plug (me/mex)			
		COP 1838	3115 3291 00	regulating plug		O	
63		COP 1838	3115 2342 00	regulating plug (he/hex)			
63		COP 1838	3115 2115 03	regulating plug (he/hex)			
63		COP 1838	3115 2115 01	regulating plug (hf)			
64		COP 1838	3115 1697 00	seal washer		O	
65		COP 1838	3115 1692 00	dome nut		O	0.06 / 3115 3214 00
		COP 1838	3115 1944 80	cylinder, compl			Manufacturing
66		COP 1838	-	-cylinder			
67		COP 1838	3115 1825 00	--pipe plug			
68		COP 1838	0686 6447 04	--plug			

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
69		COP 1838	0661 1034 00	--seal washer		0	
		COP 1838	0259 0011 00	--thread insert			
		COP 1838	0259 2061 00	--thread insert			
		COP 1838	0259 0311 00	--thread insert			
70		COP 1838	3115 2112 00	-guide		0	
71		COP 1838	3115 1165 00	-stud		0	0.02
72		COP 1838	3115 0277 00	coupling	1	0	0.38kg
73		COP 1838	0335 2130 00	circlip		0	
74		COP 1838	-	hydraulic motor			
75		COP 1838	3115 1454 00	nut		0	
76		COP 1838	0663 2115 00	o-ring			
77		COP 1838	3115 2129 00	piston (me/mex)		0	5.04kg
77		COP 1838	3115 2126 00	piston (he/hex)		0	5.5kg
77		COP 1838	3115 2989 00	piston (hf)			Need sample
78		COP 1838	0663 6138 00	o-ring			
79		COP 1838	3115 1680 00	piston guide, rear (me/mex)		0	0.34KG
79		COP 1838	3115 2124 00	piston guide, rear (he/hex)		0	0.34
79		COP 1838	3115 1833 00	piston guide, rear (hf)		0	0.34
		COP 1838	3115 2772 80	seal housing, compl (me/mex)		0	
		COP 1838	3115 2760 80	seal housing, compl (he/hex)		0	Manufacturing
		COP 1838	3115 2771 80	seal housing, compl (hf)			
80		COP 1838	-	-seal housing			
81		COP 1838	3115 1156 00	-set of seals (me/mex)		0	
81		COP 1838	3115 2554 00	-set of seals (he/hex)		0	
81		COP 1838	3115 0845 00	-set of seals (hf)		0	
82		COP 1838	0663 6135 00	-o-ring			
83		COP 1838	3115 2063 00	back head (me/mex/hf)	1	0	5.54kg
83		COP 1838	3115 2111 00	back head (he/hex)			Need sample
84		COP 1838	0147 1481 03	screw		0	
85		COP 1838	3176 6512 00	nipple			
86		COP 1838	3176 5313 00	cap			
87		COP 1838	3176 6514 00	nipple			
88		COP 1838	3715 0597 00	cap			
89		COP 1838	3115 2383 00	valve poppet		0	
90		COP 1838	0663 2129 01	o-ring			
91		COP 1838	3115 2384 00	valve seat		0	
92		COP 1838	3115 2700 80	damper accumulator		0	3115 3411 00 / 4.04KG
94		COP 1838	3115 2615 90	return accumulator (he/hex)		0	4kg
94		COP 1838	3115 2615 91	return accumulator (me/mex/hf)	1	0	4KG
95		COP 1838	3115 0327 00	gasket		0	
		COP 1838	3115 2132 03	label "cop 1838me"			
		COP 1838	3115 2132 05	label "cop 1838mex"			
		COP 1838	3115 2132 02	label "cop 1838he"			
		COP 1838	3115 2132 04	label "cop 1838hex"			
		COP 1838	3115 2132 08	label "cop 1838hf"			
96		COP 1838	3115 2988 00	seal ring		0	
97		COP 1838	0661 1026 00	seal washer (me/mex/hf)		0	0066 1026 00

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
98		COP 1838	0686 3716 06	plug (me/he/hf)		0	
		COP 1838	3115 9153 90	o-ring kit		0	
		COP 1838	FRONT HEAD	COP 1838ME/HE			
1		COP 1838	3115 2950 00	front head		0	12.2kg
2		COP 1838	3115 1938 00	connection plate		0	1.54kg
3		COP 1838	0665 1000 12	cup seal		0	
4		COP 1838	3315 0195 08	lock washer		0	
5		COP 1838	0147 1401 03	screw		0	
6		COP 1838	3176 6518 00	nipple		0	0.26kg
7		COP 1838	3115 2118 00	guide		0	1.9kg
8		COP 1838	3115 2333 00	cup seal		0	3115 3364 00
9		COP 1838	0663 2145 01	o-ring	1	0	
10		COP 1838	3115 2120 00	flushing head		0	4.3kg
11		COP 1838	0665 0999 21	cup seal		0	3115 5190 00 / 3115 3363 00
12		COP 1838	3115 2122 00	stop ring	1	0	1.58KG
13		COP 1838	0663 2143 00	o-ring		0	
14		COP 1838	3115 2119 00	guide		0	1.36kg
15		COP 1838	3115 2386 00	cup seal		0	
16		COP 1838	3115 2121 00	flushing head		0	4.5kg
17		COP 1838	3115 2693 00	cup seal		0	
		COP 1838	3115 2117 80	stop ring, compl		0	1.58KG
		COP 1838	3115 2123 80	stop ring, compl		0	1.6kg
18		COP 1838	-	-stop ring (split)			
19		COP 1838	0663 2105 96	-o-ring		0	
20		COP 1838	7304 3652 01	shank adapter,T38		0	L435 D38
21		COP 1838	7803 3655 01	shank adapter,R32E		0	
21		COP 1838	7304 3655 01	shank adapter,T38E		0	
21		COP 1838	7305 3655 01	shank adapter,T45E		0	
21		COP 1838	7306 3655 01	shank adapter,T51E		0	
21		COP 1838	7803 3656 01	shank adapter,R32E		0	
21		COP 1838	7804 3652 01	shank adapter,R38		0	
21		COP 1838	7804 3656 01	shank adapter,R38E		0	
21		COP 1838	7304 3656 01	shank adapter,T38E		0	
22		COP 1838	3115 2231 00	drill collar(R32/T38)		0	
22		COP 1838	3115 2232 00	drill colar(T45)		0	
22		COP 1838	3115 2233 00	drill collar(T51)			
		COP 1838					
		COP 1838	FRONT HEAD	COP 1838ME/HE			
1		COP 1838	3115 2950 00	front head		0	12.2kg / 3115 1945 00[Old]
2		COP 1838	3115 1938 00	connection plate		0	1.54kg / 3115 5152 00
3		COP 1838	0665 1000 12	cup seal		0	
4		COP 1838	3315 0195 08	lock washer		0	
5		COP 1838	0147 1401 03	screw		0	
6		COP 1838	3176 6518 00	nipple		0	0.26kg
7		COP 1838	3115 2118 00	guide		0	1.9kg
8		COP 1838	3115 2333 00	cup seal		0	
9		COP 1838	0663 2145 01	o-ring		0	

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
10		COP 1838	3115 2120 00	flushing head		0	4.3kg
11		COP 1838	0665 0999 21	cup seal		0	
12		COP 1838	3115 2122 00	stop ring		0	1.58KG
13		COP 1838	0663 2143 00	o-ring		0	
14		COP 1838	3115 2119 00	guide		0	1.36kg
15		COP 1838	3115 2386 00	cup seal		0	
16		COP 1838	3115 2121 00	flushing head		0	4.5kg
		COP 1838	3115 2693 00	cup seal		0	
17		COP 1838	3115 2117 80	stop ring, compl		0	1.58KG
			3115 2123 80	stop ring, compl		0	1.6kg
		COP 1838 HF	3115 2990 00	stop ring, compl			SAMPLE요망
18		COP 1838		-stop ring(split)			
19		COP 1838	0663 2105 96	-o-ing		0	
20		COP 1838	7304 3652 01	shank adapter,T38		0	
21		COP 1838	7305 3655 01	shank adapter,T45E			
21		COP 1838	7803 3656 01	shank adapter,R32E			
21		COP 1838	7804 3652 01	shank adapter,TR38E			
21		COP 1838	7304 3656 01	shank adapter,T38E			
		COP 1838		optioquinal equipment			
22		COP 1838	3115 2231 00	drill collar(R32/T38)		0	
22		COP 1838	3115 2232 00	drill collar(T45)		0	
		COP 1838					
		COP 1838	Extractor unit	COP 1838MEX/HEX			
		COP 1838	3115 2871 81	front head			
1		COP 1838		front head			
2		COP 1838	3115 2223 02	guide		0	2.48kg
3		COP 1838	0663 6147 01	o-ring			
4		COP 1838	3115 2055 00	set of seals		0	
5		COP 1838	3115 2875 00	bushing			Need sample
6		COP 1838	0335 2177 00	lock ring			
7		COP 1838	0663 2101 66	o-ring			
8		COP 1838	3115 2116 00	set of seals		0	
9		COP 1838	3115 2876 00	bushing			
10		COP 1838	3115 2520 00	piston			3115 3165 00
11		COP 1838	3115 0286 00	dome nut		0	0.26kg
12		COP 1838	3115 0287 00	washer		0	0.04kg / 0311 0287 00
13		COP 1838	3115 2221 00	stud		0	
14		COP 1838	3176 6514 00	nipple			
15		COP 1838	3715 0597 00	cap			
16		COP 1838	3176 6512 00	nipple			
17		COP 1838	3176 5313 00	cap			
19		COP 1838	3176 6568 00	nipple			
20		COP 1838	3176 6509 00	nipple			
21		COP 1838	3176 6618 00	nut			
22		COP 1838	0102 0460 00	cylindrical pin			
		COP 1838	3115 2874 80	cove compl			Need sample
23		COP 1838	-	cover			

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
24		COP 1838	0666 7190 01	seal ring		O	0.06kg
25		COP 1838	0335 2173 00	circlip		O	0.04
26		COP 1838	0663 6143 01	o-ring			
27		COP 1838	3115 2387 00	cup seal		O	
28		COP 1838	3115 2315 00	flushing head		O	
29		COP 1838	3115 2222 00	side bolt		O	
31		COP 1838	7304 3825 02	shank akapter T38E			
31		COP 1838	7305 3826 02	shank akapter T45E			
31		COP 1838	7305 3828 02	shank dadper T51E			
32		COP 1838	3115 2317 00	flushing connection			
33		COP 1838	0661 2014 00	back-up ring			
34		COP 1838	0663 9186 01 **	o-ring			
35		COP 1838	0663 2126 01 **	o-ring			
36		COP 1838	0196 1318 00	set screw			
37		COP 1838	0661 1026 00	seal washer		O	
38		COP 1838	0686 3716 06	plug		O	
		COP 1838					
39		COP 1838	3115 2231 00	drill collar		O	
39		COP 1838	3115 2232 00	drill collar		O	
39		COP 1838	3115 2233 00	drill collar			
		COP 1838					
		COP 1838	3115 1010 80	oms 100		O	10.5kg
		COP 1838	3115 1010 81	oms 160		O	11kg
		COP 1838	3115 1010 83	oms 315		O	11.5kg 3115 3473 86
		COP 1838	3115 1010 84	oms 250		O	10.5kg
		COP 1838					
1		COP 1838	3115 1010 47	bearing housing	1	O	
2		COP 1838	**	seal ring			
3		COP 1838	3115 1010 48	splined shaft		O	0.76kg
4		COP 1838	**	seal ring			
5		COP 1838	**	o-ring			
6		COP 1838	3115 1010 65	intermediate plate			
7		COP 1838	3115 0839 24	drain plug			
8		COP 1838	3115 1010 58	washer			
9		COP 1838	3115 1010 07	cardan shaft			
9		COP 1838	3115 1010 29	cardan shaft			
9		COP 1838	3115 1010 49	cardan shaft			
9		COP 1838	3115 1010 59	cardan shaft			
10		COP 1838	**	o-ring			
11		COP 1838	3115 1010 43	cog wheel set			
11		COP 1838	3115 1010 50	cog wheel set			
11		COP 1838	3115 1010 70	cog wheel set			
11		COP 1838	3115 1010 60	cog wheel set			
12		COP 1838	3115 1010 71	channel plate			
13		COP 1838	3115 1010 76	check valve ball			
14		COP 1838	3115 1010 12	valve drive			
15		COP 1838	3115 1010 14	disc valve			

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
16		COP 1838	3115 1010 72	balance plate			
17		COP 1838	3115 1010 73	guide pin			
18		COP 1838	**	o-ring			
19		COP 1838	**	o-ring			
20		COP 1838	3115 1010 19	spacer pin			
21		COP 1838	3115 1010 74	spring ring			
22		COP 1838	3115 1010 75	valve houshing			
23		COP 1838	**	seal plug			
24		COP 1838	3115 1010 44	screw			
24		COP 1838	3115 1010 52	screw			
24		COP 1838	3115 1010 53	screw			
24		COP 1838	3115 1953 00	screw			
25		COP 1838	**	seal ring			
		COP 1838	3115 2696 80	accumulator		0	4.04KG / 3115 3511 81
1		COP 1838	*	hosing			
2		COP 1838	3115 1822 00	diaphragm		0	0.04kg
3		COP 1838	*	cover			
4		COP 1838	3115 2702 00	screw		0	0.12kg
		COP 1838	3115 2196 81	test valve compl		0	0.03kg
5		COP 1838	*	valve body			
6		COP 1838	0663 6121 00**	o-ring		0	
7		COP 1838	0663 2110 00**	o-ring		0	
8		COP 1838	*	poussoir de soupape			
		COP 1838	3115 0262 00	valve compl		0	0.04kg
9		COP 1838	*	valve			
10		COP 1838	3310 4076 00	cap		0	
11		COP 1838	0663 9056 00**	o-ring			
12		COP 1838	3115 2629 00	safety label			
		COP 1838		(see instruction book)			
13		COP 1838	3115 2630 00	safety label			
14		COP 1838	3115 2714 00	dat label			
		COP 1838	3115 2900 80			0	7.44kg
1		COP 1838	*	housing		0	
2		COP 1838	3115 2902 00	nut		0	
3		COP 1838	3115 2903 00	compression spring		0	
4		COP 1838	3115 2901 00	diaphragm support		0	
5		COP 1838	3115 2472 00	diaphragm		0	0.03kg
6		COP 1838	*	cover			
7		COP 1838	3115 2703 00	screw			
		COP 1838	3115 2196 81	test valve compl		0	0.03kg
8		COP 1838	*	valve body			
9		COP 1838	0663 6121 00**	o-ring		0	
10		COP 1838	0663 2110 00**	o-ring		0	
11		COP 1838	*	valve plunger			
		COP 1838	3115 0262 00	valve compl.		0	0.04kg
12		COP 1838	*	valve			
13		COP 1838	3310 4076 00	cap		0	

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
14		COP 1838	0663 9056 00**	o-ring			
15		COP 1838	3115 2629 00	safety label			
		COP 1838		(see instruction book)			
16		COP 1838	3115 2630 00	safety label			
17		COP 1838	3115 2712 00	data label			
		COP 1838	3115 2700 80	accumulator 3115 2700 00		0	3115 3451 00 / 4.04KG / 3115 2395 80[01d]
		COP 1838	3115 3451 81	accumulator			Manufacturing
1		COP 1838	*	hosuing			
2		COP 1838	3115 1822 00	diaphragm		0	0.04kg
3		COP 1838	*	cover			
		COP 1838	3115 0262 00	valve compl		0	0.04kg
4		COP 1838	*	valve			
5		COP 1838	3310 4076 00	cap			
6		COP 1838	0663 9056 00**	o-ring			
		COP 1838	3115 2196 81	test valve compl		0	0.03kg
7		COP 1838	*	valve body			
8		COP 1838	0663 6121 00**	o-ring		0	
9		COP 1838	0663 2110 00**	o-ring		0	
10		COP 1838	*	valve plunger			
11		COP 1838	3115 2629 00	safety label			
		COP 1838		9see instruction book)			
12		COP 1838	3115 2630 00	safety label			
13		COP 1838	3115 2702 00	screw			
		COP 1838					
		COP 1838	3115 2615 91	retum accumulator		0	4KG
1		COP 1838	3115 1926 02	diaphragm		0	0.03kg
2		COP 1838	*	tube		0	
3		COP 1838	3176 6528 00	nipple		0	
4		COP 1838	0661 1038 00	seal ring		0	
5		COP 1838	0663 2128 00	o-ring		0	
6		COP 1838	3115 2618 00	cover		0	
7		COP 1838	3115 2886 00	tube		0	
8		COP 1838	9125 6191 00	o-ring			
9		COP 1838	3115 2885 00	tube cover		0	
10		COP 1838	3115 2889 00	pressure screw		0	0.26kg
11		COP 1838	3115 2617 10	plug		0	
11		COP 1838	3115 2617 20	plug		0	
12		COP 1838	0663 2109 37	o-ring		0	있음
13		COP 1838	0663 2129 01	o-ring		0	있음
		COP 1838	3115 2275 80	holder compl		0	0.78kg
14		COP 1838	3115 2276 00	holder			
15		COP 1838	3115 2275 00	clamp			
16		COP 1838	0147 1328 03	screw		0	
17		COP 1838	0291 2819 00	lock nut		0	
18		COP 1838	0147 1483 03	screw		0	
		COP 1838					
		COP 1838	3115 2615 90	retum accumulator		0	4kg

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
1		COP 1838	3115 1926 02	diaphragm 3115 1926 00		0	0.03kg
2		COP 1838	*	tube		0	
3		COP 1838	3176 6528 00	nipple		0	
4		COP 1838	0661 1038 00	seal ring		0	
5		COP 1838	0663 2128 00	o-ring			
6		COP 1838	3115 2618 00	cover		0	
7		COP 1838	3115 2380 00	flange tube	1	0	
8		COP 1838	9125 6191 00	o-ring			
9		COP 1838	0663 9104 01	o-ring			
10		COP 1838	3115 2379 00	seal			
11		COP 1838	3115 2617 10	plug		0	
		COP 1838	3115 2275 80	holder compl			0.78kg
12		COP 1838	3115 2276 00	holder			Manufacturing
13		COP 1838	3115 2275 00	clamp			
14		COP 1838	0147 1328 03	screw		0	
15		COP 1838	0291 2819 00	lock nut		0	
16		COP 1838	0147 1483 03	screw		0	
17		COP 1838	3176 6567 00	nipple			
		COP 1838	3115 0262 00	valve compl		0	0.04kg
18		COP 1838	*				
19		COP 1838	3310 4076 00	cap			
20		COP 1838	0663 9056 00	o-ring			
		COP 1838					
		COP 1838	3115 7603 91	set of nipples compl			
1		COP 1838	3177 3046 00	nipple for percussion medchanism			
2		COP 1838	3176 6565 00	nipple for rotation motor			
3		COP 1838	3115 1459 00	nipple for totation motor			
4		COP 1838	3176 6515 00	nipple for rotation motor			
		COP 1838	3115 1603 91			0	1.04KG
		COP 1838	3115 1605 91			0	
1		COP 1838	3176 6517 00	nipple for percussion mecganism			
2		COP 1838	3176 6516 00	nipple for rotation motor			
3		COP 1838	3176 6550 00	nipple for rotation motor			
		COP 1838	3115 9150 96	o-ring kit		0	0.64kg
		COP 1838	3115 2275 80	HOLDER COMPL set		0	0.78, holder compl
			3115 2950 00	front head		0	12.2KG 3115 1945 00[Old]
			3115 1822 01	diaphragm		0	0.03
			3115 1880 90	seal kit		0	0.06
			3115 9153 90	o-ring kit		0	
			3115 3473 83	HYDRAULIC MOTOR			MSQ 160 SH
			3115 2118 00	guide		0	1.9 KG
			3115 5042 00	FRONT HEAD			Manufacturing
			3128 0484 00	cradle plate		0	4.04
			3128 3061 81	holder			
			3115 9238 90	400 hours rebuild kit		0	12.5kg
			3115 2971 00	damping piston		0	2.9KG PM

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
			3115 2118 90	Rebuild kit COP 1838ME-T38		0	29KG
			3115 2118 90	Rebuild kit COP 1838ME-T38 without Piston		0	24KG
			3115 3473 90	set of seals		0	
			3128 0782 58	cradle plate		0	
			3128 3061 74	cradle		0	15.32
			3128 0784 11	pull rope		0	2.56
			3128 0784 14	return rope		0	2.6
			3115 1886 00				
			7306 3655 01	COP1550 /1838me(L525)T51		0	2012-10-24
			3115 5044 00	FLUSHING HEAD	1	0	1.5kg
			3115 5045 01	GUIDE	1	0	1.5kg
			3115 5042 00	FRONT PART		0	20kg
			3115 2971 00	Damper Piston		0	2.9
			3115 3744 00	Bushing		0	0.08, 3115 2084 00
			3125 4968 80	Expanding Shaft		0	
			3128 0034 01	Slide Bar			
			3128 0083 00	Holder		0	
			3128 3140 12	Holder set		0	0.5, 1 set
			3128 3140 13	Holder set		0	0.5, 1 set
			3128 0784 39	Holder		0	0.92
			3128 0784 38	Holder		0	0.92
			5112 3021 12	Pump			
			3128 0551 01	Return Rope		0	1.66
			3128 0647 02	Pull Rope		0	1.72
			3128 0781 97	Pull Rope		0	2.5
			3128 0782 66	Nipple			
			3128 0893 00	Profile		0	
			3128 2287 55	Sliding Piece			
			3128 3069 51	Shaft		0	
			3217 8762 00	Hydraulic Pump			
			5112 2931 00	Lubrication Pump			
			3128 3039 30	Sliding Piece		0	
		COP1838	3115 2968 00	BUSHING		0	1.04
		COP1838	3115 3474 00	LINER		0	1.16
			3115 3023 00				
			3115 2692 80				
			3115 9011 65	SERVICE KIT 400 HOURS		0	
			3115 9011 66	SERVICE KIT 800 HOURS		0	
			3115 9011 64	SERVICE KIT		0	
			3115 2702 10	SCREW		0	
			3115 2703 00	SCREW		0	
			3115 3548 00	NUT		0	
			0018 4635 75	POLYWOOD BOX			Not available
			0147 1401 03	SCREW		0	
			0147 1438 03	SCREW		0	
			0690 1132 00	PLATE			Not available

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
			3115 2712 90	LABEL			Not available
			3115 3309 00	LABEL			Not available
			3115 3597 00	LABEL			Not available
			3115 3031 00	Guide		0	0.24
			3128 3016 84	Intermediate Support			Manufacturing
			3128 2301 03	Spring Big		0	0.52
			3128 0784 35	Spring Small		0	0.32
			3128 3035 27	Dowel		0	4.64
			3128 0785 48	Holder Right		0	0.46
			3128 0785 49	Holder Left		0	0.46
			3128 0785 34	Pully Wheel		0	3
			3128 0704 27	Roller Bearing		0	0.46 / 3128 0784 27
			3128 0481 00	Shaft		0	
			3128 3025 49	Front Bush		0	D-47
			3128 3025 53	Rear Bush		0	0.3 / D-39
			3128 0784 37	Cradle Plate		0	4.96
			7994-3655	Coupling Sleeves R38		0	R38*R38 D54 *175
			7804-3652-01	Shank Adaptor R38 for COP 1838 (L2D) (Face Drilling)		0	
			7804-3590-03	Shank Adaptor R38 for COP 1238 (352) (Rock Drilling)		0	
			7304 3652 01 / 90516120	435-09103-00 COP1838(L435)T38		0	