

COP 1850 Drifter Parts for Atlas Copco

COP1850

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
2		COP 1850	3115 0286 00	DOME NUT	4		
3		COP 1850	3115 0287 00	WASHER	4		
4		COP 1850	3115 2652 00	SIDE BOLT	1		
5		COP 1850	3115 2651 00	SIDE BOLT (1850)	2		
		COP 1850	3115 2949 80	COVER COMPL.	1		
6		COP 1850		COVER	1		
7		COP 1850	0666 7190 01	SEAL RING	1		
8		COP 1850	0335 2173 00	LOCK RING	1		
9		COP 1850	0102 0482 00	CYLINDIRCAL PIN (1850)	1		
10		COP 1850	0663 2101 66	O-RING	2		
11		COP 1850	3115 0297 01	SHIM 0,10 MM	A)		
11		COP 1850	3115 0297 02	SHIM 0,15 MM	A)		
11		COP 1850	3115 0297 03	SHIM 0,05 MM	A)		
12		COP 1850	0509 0223 00	ROLLER BERAING	1		
13		COP 1850	3115 2650 00	DRIVER	1		
		COP 1850	3115 2649 80	ROTATION CHUCK COMPL.	1		
14		COP 1850		ROTATION CHUCK	1		
15		COP 1850	3115 1881 00	BUSHING	1		
16		COP 1850	0509 0221 00	ROLLER BERAING	1		
		COP 1850	3115 2340 80	GEAR HOUSING COMPL.	1		
17		COP 1850		GEAR HOUSING	1		
18		COP 1850	0686 4201 03	PLUG	1		
19		COP 1850	0653 9038 00	GASKET	1		
20		COP 1850	0544 2162 00	LUBRICATING NIPPLE	1		
21		COP 1850	0666 7188 01	SEAL RING	1		
22		COP 1850	0335 2169 00	LOCK RING	1		
23		COP 1850	3115 0273 00	WASHER	1		
24		COP 1850	0663 2120 00	O-RING	2		
25		COP 1850	3115 2968 00	ROTATION CHUCK BUSHING	1		
		COP 1850	3115 0821 80	SHAFT COMPL.	1		
26		COP 1850		SHAFT	1		
27		COP 1850	0516 1504 01	NEEDLE BEARING	1		
28		COP 1850	3115 0823 00	WASHER	1		
29		COP 1850	0516 1538 00	NEEDLE BEARING	1		
30		COP 1850	3115 0824 00	SLEEVE	1		
31		COP 1850	0667 1206 00	CUP SEAL	1		
32		COP 1850	3115 2742 00	GUIDE SLEEVE	1		
33		COP 1850	3115 0274 00	GEAR	1		
34		COP 1850	0663 2133 01	O-RING	3		
35		COP 1850	3115 2971 00	DAMPING PISTON	1		

Driven by our values :

Honesty, Integrity, Accountability, Quality and Service Excellence!!!!

ERG Korea CO., Ltd.

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
		COP 1850	3115 2583 84	INTERMEDIATE PART COMPL.	1		
36		COP 1850		INTERMEDIATE PART	1		
		COP 1850	0259 2061 00	THREAD INSERT	4		
		COP 1850	0259 0068 00	THREAD INSERT	2		
37		COP 1850	3115 1746 06	NOZZLE	2		
38		COP 1850	0196 1318 00	SET SCREW	1		
39		COP 1850	0686 6442 00	PLUG	1		
40		COP 1850	0661 1020 00	SEAL WASHER	1		
41		COP 1850	3115 2670 00	LINER	1		
42		COP 1850	0663 2104 94	O-RING	1		
43		COP 1850	0663 2105 96	O-RING	1		
44		COP 1850	0335 3500 10	LOCK RING	1		
45		COP 1850	3115 2084 00	BUSHING	1		
46		COP 1850		SET OF SEALS	1		
47		COP 1850		SET OF SEALS	1		
48		COP 1850	3115 2884 00	CONNECTION PLATE	1		
49		COP 1850	0211 1960 84	SCREW	2		
50		COP 1850	0663 2100 62	O-RING	2		
51		COP 1850	0686 9110 00	PROTECTIVE PLUG	1		
52		COP 1850	3115 2900 80	INTAKE ACCUMULATOR COMPL.	1		
		COP 1850	3115 2759 80	SEAL HOUSING COMPL.	1		
53		COP 1850		SEAL HOUSING	1		
54		COP 1850	3115 2559 00	SET OF SEALS	2		
55		COP 1850	0663 6136 00	O-RING	1		
56		COP 1850	0663 6143 00	O-RING	1		
57		COP 1850	3115 2558 00	PISTON GUIDE FRONT	1		
58		COP 1850	0663 6134 01	O-RING	2		
59		COP 1850	3115 1765 00	VALVE PISTON	1		
60		COP 1850	3115 2077 05	VALVE COVER LEFT	1		
61		COP 1850	3115 2076 03	VALVE COVER RIGHT	1		
62		COP 1850	0147 1438 03	SCREW	4		
63		COP 1850	3115 2115 02	REGULATING PLUG	1		
63		COP 1850	3115 2115 01	REGULATING PLUG	1		
64		COP 1850	3115 1697 00	SEAL WASHER	2		
65		COP 1850	3115 1692 00	DOME NUT	1		
		COP 1850	3115 1944 80	CYLINDER COMPL.	1		
66		COP 1850		CYLINDER	1		
67		COP 1850	3115 1825 00	PIPE PLUG	1		
68		COP 1850	0686 6447 04	PLUG	2		
69		COP 1850	0661 1034 00	SEAL WASHER	2		
		COP 1850	0259 0011 00	THREAD INSERT	4		
		COP 1850	0259 2061 00	THREAD INSERT	3		
		COP 1850	0259 0311 00	THREAD INSERT	1		
70		COP 1850	3115 2112 00	GUIDE	1		
71		COP 1850	3115 1165 00	STUD	4		
72		COP 1850	3115 0277 00	COUPLING	1		
73		COP 1850	0335 2130 00	CIRCLIP	1		

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
74		COP 1850		HYDRAULIC MOTOR	1		
75		COP 1850	3115 1454 00	NUT	4		
76		COP 1850	0663 2115 00	O-RING	1		
77		COP 1850	3115 2853 01	PISTON	1		
78		COP 1850	0663 6138 00	O-RING	1		
79		COP 1850	3115 2124 00	PISTON GUIDE,REAR	1		
		COP 1850	3115 2760 80	SEAL HOUSING,COMPL.	1		
80		COP 1850		SEAL HOUSING	1		
81		COP 1850	3115 2554 00	SET OF SEALS	2		
82		COP 1850	0663 6135 00	O-RING	1		
83		COP 1850	3115 2977 00	BACK HEAD	1		
84		COP 1850	0147 1481 03	SCREW	3		
85		COP 1850	3176 6512 00	NIPPLE	2		
86		COP 1850	3176 5313 00	CAP	2		
87		COP 1850	3176 6514 00	NIPPLE	1		
88		COP 1850	3715 0597 00	CAP	1		
89		COP 1850	3115 2383 00	VALVE POPPET	1		
90		COP 1850	0663 2129 01	O-RING	1		
91		COP 1850	3115 2384 00	VALVE SET	1		
92		COP 1850	3115 2700 80	DAMPER ACCUMULATOR	1		
94		COP 1850	3115 2615 90	RETURN ACCUMULATOR	1		
95		COP 1850	3115 2945 00	BREATHER	1		
97		COP 1850	3176 6517 00	NIPPLE	1		
98		COP 1850	3715 0820 00	CAP	3		
99		COP 1850	3176 6516 00	NIPPLE	2		
100		COP 1850	3176 6550 00	NIPPLE	2		
101		COP 1850	3115 2648 00	EXTENSION PIECE	1		
102		COP 1850	3115 0327 00	GASKET	1		
		COP 1850	3115 2560 02	LABEL "COP 1850"	1		
		COP 1850	3115 2560 03	LABEL "COP 1850EX"	1		
103		COP 1850	3115 2988 00	SEAL RING	2		
104		COP 1850	0661 1026 00	SEAL WASHER	1		
105		COP 1850	0686 3716 06	PLUG	1		
1		COP 1850	3115 2950 00	FRONT HEAD	1		
2		COP 1850	3115 1938 00	CONNECTION PLATE	1		
3		COP 1850	0665 1000 12	CUP SEAL	1		
4		COP 1850	3315 0195 08	LOCK WASHER	4		
5		COP 1850	0147 1401 03	SCREW	4		
6		COP 1850	3176 6520 00	NIPPLE	1		
9		COP 1850	0663 2145 01	O-RING	3		
13		COP 1850	0663 2143 00	O-RING	1		
14		COP 1850	3115 2119 00	GUIDE	1		
15		COP 1850	3115 2386 00	CUP SEAL	2		
16		COP 1850	3115 2121 00	FLUSHING HEAD	1		
17		COP 1850	3115 2693 00	CUP SEAL	1		
		COP 1850	3115 2117 80	STOP RING,COMPL.	1		
18		COP 1850		STOP RING (SPLIT)	1		

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
19		COP 1850	0663 2105 96	O-RING	1		
21		COP 1850	7305 3690 02	SHANK ADAPTER,T45	1		
21		COP 1850	7306 3690 02	SHANK ADAPTER,T51	1		
22		COP 1850	3115 2232 00	DRILL COLLER(FRO DRILLING UPWARDS T45)	1		
22		COP 1850	3115 2233 00	DRILL COLLER(FRO DRILLING UPWARDS T51)	1		
		COP 1850	3115 2871 81	FRONT HEAD,COMPL.	1		
1		COP 1850		FRONT HEAD	1		
2		COP 1850	3115 2223 02	GUIDE	1		
3		COP 1850	0663 6147 01	O-RING	1		
4		COP 1850	3115 2055 00	SET OF SEALS	1		
5		COP 1850	3115 2875 00	BUSHING	1		
6		COP 1850	0335 2177 00	LOCK RING	1		
7		COP 1850	0663 2101 66	O-RING	3		
8		COP 1850	3115 2116 00	SET OF SEALS	1		
9		COP 1850	3115 2876 00	BUSHING	1		
10		COP 1850	3115 3165 00	PISTON	1		
11		COP 1850	3115 0286 00	DOME NUT	3		
12		COP 1850	3115 0287 00	WASHER	3		
13		COP 1850	3115 2221 00	STUD	3		
14		COP 1850	3176 6514 00	NIPPLE(INTAKE)	1		
15		COP 1850	3715 0597 00	CAP	1		
16		COP 1850	3176 6512 00	NIPPLE(RETURN)	1		
17		COP 1850	3176 5313 00	CAP	1		
19		COP 1850	3176 6568 00	NIPPLE	1		
22		COP 1850	0102 0460 00	CYLINDIRICAL PIN	1		
		COP 1850	3115 2874 80	COVER,COMPL.	1		
23		COP 1850		COVER	1		
24		COP 1850	0666 7190 01	RADIAL LIP SEAL	1		
25		COP 1850	0335 2173 00	CIRCLIP	1		
26		COP 1850	0663 6143 01	O-RING	4		
27		COP 1850	3115 2387 00	CUP SEAL	4		
28		COP 1850	3115 2315 00	FLUSHING HEAD	1		
29		COP 1850	3115 2653 00	SIDE BOLT	2		
31		COP 1850	7305 3890 02	SHANK ADAPTER,T45E	1		
31		COP 1850	7306 3890 02	SHANK ADAPTER,T51E	1		
32		COP 1850	3115 2317 00	FLUSHING CONNECTION	1		
33		COP 1850	0661 2014 00	BACK-UP RING	1		
34		COP 1850	0663 9186 01	O-RING	1		
35		COP 1850	0663 2126 01	O-RING	1		
36		COP 1850	0196 1318 00	SET SCREW	2		
37		COP 1850	0102 0476 00	CYLINDIRICAL PIN	1		
38		COP 1850	0661 1026 00	SEAL WASHER	1		
39		COP 1850	0686 3716 06	PLUG	1		
40		COP 1850	3115 2232 00	DRILL COLLAR(FOR DRILLING UPWARDS T45)	1		
40		COP 1850	3115 2233 00	DRILL COLLAR(FOR DRILLING UPWARDS T51)	1		
1		COP 1850		HOUSING	1		
2		COP 1850	3115 2902 00	NUT	1		

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
3		COP 1850	3115 2903 00	COMPRESSION SPRING	1		
4		COP 1850	3115 2901 00	DIAPHRAGM SUPPORT	1		
5		COP 1850	3115 2472 00	DIAPHRAGM	1		
6		COP 1850		COVER	1		
7		COP 1850	3115 2703 00	SCREW	2		
		COP 1850	3115 2196 81	TEST VALVE,COMPL.	1		
8		COP 1850		VALVE BODY	1		
9		COP 1850	0663 6121 00	O-RING	1		
10		COP 1850	0663 2110 00	O-RING	1		
11		COP 1850		VALVE PLUNGER	1		
		COP 1850	3115 0262 00	VALVE,COMPL.	1		
12		COP 1850		VALVE	1		
13		COP 1850	3310 4076 00	CAP	1		
14		COP 1850	0663 9056 00	O-RING	1		
15		COP 1850	3115 2629 00	SAFETY LABEL	1		
16		COP 1850	3115 2630 00	SAFETY LABEL	1		
17		COP 1850	3115 2712 00	DATA LABEL	1		