

HLX5 Drifter Parts

TAMROCK

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
		HLX5	550 467 92	HYDRAULIC ROCK DRILL HLX 5			
1		HLX5	152 749 48	FLUSHING DEVICE ASSEMBLY	1		SEP. PART LIST, INCL. PART 39
2		HLX5	550 466 28	GEARBOX	1		SEP. PART LIST
8		HLX5	550 577 98	ROTATION BUSHING	1		INCL. PART 60
9		HLX5	152 508 28	COUPLING	1		
		HLX5	550 508 28	COUPLING			
16		HLX5	154 194 08	GEAR WHEEL	1		0.7
17		HLX5	154 217 48	ROTATION SHAFT	1		1.7
18		HLX5	550 007 62	BEARING BUSHING	1		INCL. PART 59
19		HLX5	150 797 18	SLIDE WASHER	2		0.3
20		HLX5	152 716 38	STUD	6		0.5
21		HLX5	152 525 68	CAP NUT	6		0.5
23		HLX5	550 034 00	SCREW	4		0.28
26		HLX5	887 946 09	SHAFT SEAL	1		TG3100300--T10
27		HLX5	511 108 30	DEEP GROOVE BALL BEARING	1		
39		HLX5	152 748 18	GASKET	1		
42		HLX5	800 658 09	O--RING	1		74,5X3--1, SMS 1586
44		HLX5	853 575 89	O--RING	1		41,2X3--1, NBR, 70 SHORE A
46		HLX5	047 689 68	RUBBER COVER	1		1 1/2" SHANK
47		HLX5	280 678 90	HOSE CLAMP	1		50 SMS 2298
59		HLX5	888 097 49	BEARING	1		
60		HLX5	152 723 68	CHUCK	1		
		HLX5		PARTS TO BE ORDERED SEPARATELY:			
		HLX5	550 252 93	SEAL KIT FOR ROCK DRILL			INCL. PARTS 26. 39. 44
		HLX5	550 065 07	SPECIAL TOOLS			SEP. PART LIST
1		HLX5	550 103 31	BODY	1		SEP. PART LIST
4		HLX5	550 036 25	LOW PRESSURE ACCUMULATOR	1		7.44, SEP. PART LIST
5		HLX5	550 036 27	HIGH PRESSURE ACCUMULATOR	1		7.44, SEP. PART LIST
10		HLX5	152 715 08	FRONT BUSHING	1		1.5
11		HLX5	302 969 08	PISTON	1		5.5KG
12		HLX5	550 047 84	CYLINDER PILOT CYLINDER	1		6.1
13		HLX5	152 576 38	DISTRIBUTOR	1		
14		HLX5	550 023 18	BUSHING REAR BUSHING ASSY	1		
15		HLX5	550 026 37	COVER REAR	1		
22		HLX5	550 065 21	ROTATION MOTOR	1		SEP. PART LIST
24		HLX5	887 944 59	PISTON ROD SEAL 2	2		
25		HLX5	887 945 89	PISTON ROD SEAL 2	2		
28		HLX5	550 042 26	GASKET PLATE	2		ACCUMULATOR
29		HLX5	802 198 29	BOLT	8		M16X70 -- 8.8
30		HLX5	850 687 49	DOUBLE LOCK WASHER	8		M16
36		HLX5	550 046 25	GASKET	1		

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
37		HLX5	800 470 59	HEX. HEAD SCREW	4		M12X30 -- 8.8
38		HLX5	851 068 09	DOUBLE LOCK WASHER	4		M12
41		HLX5	801 368 49	O--RING	2		59,5X3, NBR
42		HLX5	800 658 09	O--RING	8		74,5X3--1 SMS 1586
43		HLX5	550 091 05	O--RING	2		55X2 90SHORE A
		HLX5		PARTS TO BE ORDERED SEPARATELY:			
		HLX5	550 252 93	SEAL KIT FOR ROCK DRILL			INCL. PARTS 24. 25. 28. 36. 41--43
		HLX5	550 065 07	SPECIAL TOOLS			SEP. PART LIST
		HLX5	152 749 48	FLUSHING DEVICE ASSEMBLY			HLX5 AND HLX5T,
		HLX5		UNDERGROUND APPLICATIONS, SHANK 45			
1		HLX5	550 056 39	FRAME ASSEMBLY / FLUSH HEAD	1		INCL. PARTS 50--53
2		HLX5	152 745 38	FRONT COVER	1		1.72, INCL. PARTS 80--81
3		HLX5	152 747 98	SHANK BUSHING	1		1.22, INCL. PARTS 82--83
4		HLX5	150 809 18	GASKET PLATE	1		1x95
5		HLX5	300 637 10	O--RING	1		62,2X3, NBR, 70 SHORE A
6		HLX5	152 748 18	GASKET PLATE	1		1x182x184
7		HLX5	872 189 39	U--SEAL	5		0.02, 45--60X10
8		HLX5	442 218 50	HEXAGON HEAD SCREW	4		M1640 m8.8 SFS 2064
9		HLX5	850 687 49	DOUBLE LOCK WASHER	4		M16
10		HLX5	550 695 68	SEAL HOUSING	1		INCL. PARTS 84--85
12		HLX5	550 056 76	ADAPTER ASSEMBLY	1		13500, INCL. PARTS 86--88
13		HLX5	800 816 79	O--RING	1		124,5X3--1
50		HLX5	NSS	FLUSHING DEVICE BODY	1		
51		HLX5	881 140 79	PLUG	1		R1/2", E336--1/2"
52		HLX5	865 683 09	PLUG	1		R1/8", E336--1/8"
53		HLX5	550 093 63	PLUG	1		INCL. PART 89
		HLX5		PARTS TO BE ORDERED SEPARATELY:			
80		HLX5	NSS	FRONT COVER	1		FOR PART 2
81		HLX5	152 744 08	BEARING BUSHING	1		D55 d45 L70, FOR PART 2
82		HLX5	152 697 08	BUSHING	1		D68 d45 L56, FOR PART 3
83		HLX5	NSS	SHANK BUSHING	1		D68 d47 L43,5, FOR PART 3
84		HLX5	550 653 80	SEAL HOUSING, GUIDE RINGS	1		FOR PART 10
85		HLX5	550 668 36	SLYD--RING	2		FOR PART 10
86		HLX5	550 032 32	ADAPTER	1		FOR PART 12
87		HLX5	812 949 59	LOCK NUT	1		R 3/4", FOR PART 12
88		HLX5	800 348 19	USIT--SEAL	1		U 27,2x36x2, FOR PART 12
89		HLX5	871 692 89	PLUG	1		R1/4", E336--1/4", FOR PART 53
		HLX5		SEAL KIT FOR ROCK DRILL			INCL. PARTS 4--7,13
		HLX5		NSS = NOT SOLD SEPARATELY			
		HLX5	550 466 28	GEARBOX			
2		HLX5	152 711 08	BEARING BUSHING	1		D135 d130 L40
3		HLX5	550 356 04	BEARING BUSHING	1		
4		HLX5	150 259 08	BEARING HOUSING	1		0.25, INCL. PART 20
5		HLX5	865 683 09	PLUG	1		R1/8"
6		HLX5	522 107 40	O--RING	1		26,2X3--1

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
7		HLX5	550 036 03	SCREW	1		
8		HLX5	801 802 69	USIT--SEAL	1		U 13,7X22X1,5 D2=15,4
9		HLX5	871 692 89	PLUG	1		R1/4"
20		HLX5	815 035 19	BEARING	1		d=3/4" D=1" B=5/8"
		HLX5	550 103 31	BODY			
1		HLX5	550 031 58	BODY	1		
2		HLX5	150 221 58	PLUG SCREW	2		
3		HLX5	522 067 70	O--RING	2		17,3X2,4--1 , NBR , 70 SHORE A
4		HLX5	881 140 79	PLUG SCREW	11		R1/2" ,E336--1/2"
5		HLX5	882 322 79	SPRING--TYPE STRAIGHT PIN	1		5X12
6		HLX5	550 093 63	PLUG SCREW	1		
7		HLX5	871 692 89	PLUG SCREW	3		R1/4" , E336--1/4"
8		HLX5	881 139 09	PLUG SCREW	8		R3/8" , E336--3/8"
9		HLX5	152 538 58	PLATE	1		
10		HLX5	152 539 88	GASKET PLATE	1		
11		HLX5	818 735 39	O--RING	1		32,2X3, 88NBR/156
12		HLX5	800 537 39	HEX. HEAD SCREW	3		M16X35 -- 8.8
13		HLX5	850 687 49	DOUBLE LOCK WASHER	3		M16
14		HLX5	881 141 09	PLUG	6		R3/4"
15		HLX5	817 094 69	STRAIGHT THREAD ADAPTER	1		3/4--16 JIC
16		HLX5	816 768 29	STRAIGHT THREAD ADAPTER	2		1,1/16--12 JIC
17		HLX5	817 097 49	PLUG	1		3/4--16 JIC
18		HLX5	816 909 59	PLUG	2		1,1/16--12 JIC
48		HLX5	816 698 29	STRAIGHT THREAD ADAPTER	2		7/8--14JIC
49		HLX5	816 749 39	PLUG	2		7/8--14JIC
		HLX5		PARTS TO BE ORDERED SEPARATELY			
21		HLX5	808 788 39	O--RING	3		22,3X2,4 , NBR 156 , 90 SHORE A
40		HLX5	550 152 17	O--RING	1		245X3 , NBR
		HLX5		SEAL KIT FOR ROCK DRILL			INCL. PARTS 3. 10--11. 20--22. 40.
		HLX5	550 036 25	LOW PRESSURE ACCUMULATOR			
3		HLX5	092 602 98	DIAPHRAGM	1		0.02
4		HLX5	807 590 69	VALVE ASSY	1		0.04, INCL. PARTS 8. 9.
5		HLX5	522 134 90	O--RING	1		129,5X3 , NBR , 70
6		HLX5	819 532 09	O--RING	1		64,5X3 64,5X3 SMS 1586, 88 NBR/156, 90 ShA
7		HLX5	151 548 58	PLATE	1		
8		HLX5	808 010 69	O--RING	1		14X1,78
9		HLX5	851 682 19	CAP	1		
		HLX5		SEAL KIT FOR ROCK DRILL			INCL. PARTS 5--6
		HLX5	550 036 27	HIGH PRESSURE ACCUMULATOR			
3		HLX5	092 602 98	DIAPHRAGM	1		0.02
4		HLX5	807 590 69	VALVE ASSY	1		0.04, INCL. PARTS 8. 9.
5		HLX5	522 134 90	O--RING	1		129,5X3 , NBR , 70
6		HLX5	819 532 09	O--RING	1		64,5X3 64,5X3 SMS 1586, 88 NBR/156, 90 ShA
7		HLX5	151 548 58	PLATE	1		

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
8		HLX5	808 010 69	O--RING	1		14X1,78
9		HLX5	851 682 19	CAP	1		
		HLX5		SEAL KIT FOR ROCK DRILL			INCL. PARTS 5--6
		HLX5	550 065 21	ASSEMBLY KIT OMS 125			
1		HLX5		PLATE	1		INCL. PARTS 9--11
2		HLX5		FLANGE / ROTATION MOTOR	1		
3		HLX5	150 800 72	BUTTON	1		
4		HLX5	800 658 09	O--RING	1		74,5X3--1 SMS 1586
5		HLX5	550 065 90	STUD	4		FOR OMS--MOTORS HLX5
6		HLX5	851 068 09	LOCK WASHER	4		M12
7		HLX5	811 260 29	NUT	4		VM12 -- 8
8		HLX5	855 207 09	O--RING	1		70X2 , 90
9		HLX5	855 206 89	O--RING	1		45X2
10		HLX5	814 872 89	O--RING	1		24X2
11		HLX5	550 091 04	O--RING	2		82X2
12		HLX5	550 351 48	SPRING WASHER	1		
		HLX5		SEAL KIT FOR ROCK DRILL			INCL. PARTS 4. 8--11
		HLX5	550 065 06	seal kit for rock drill			
		HLX5	7304 7586 01	905 161 99 HLX5 D45 T38 L575			Shank 90516199
			330 016 98	SKID slide piece			
			263 375 08	FRAME STRIP			
		HLX5	550 065 07	SPECIAL TOOLS FOR ROCK DRILLS HLX / HFX 5 SERIES			
1		HLX5	550 056 57	PUNCH	1		NEEDLE BEARING ASSY Ø 30mm, STAB
2		HLX5	152 248 88	PUNCH	1		FRONT BEARINGS ASSY
3		HLX5	550 055 88	PUNCH	1		FOR SEAL HOUSING REMOVAL
4		HLX5	550 057 30	PUNCH	1		FOR CHUCK BEARING REMOVAL
5		HLX5	150 545 68	PUNCH	1		FRONT BEARINGS
6		HLX5	550 055 68	PUNCH	1		FRONT BEARING ASSY
7		HLX5	151 866 08	HANDLE	1		FOR PUNCHES
8		HLX5	550 056 20	PUNCH	1		FOR PILOT CYLINDER REMOVAL
9		HLX5	150 546 98	THRUST	1		FRONT BEARINGS OUT
10		HLX5	150 551 68	PUNCH	1		FRONT NEEDLE BEARING OUT
11		HLX5	550 055 57	PUNCH	1		REAR BEARING ASSY. Ø 112mm
12		HLX5	550 054 94	PUNCH	1		FOR REAR BEARING REMOVAL
13		HLX5	550 054 80	PUNCH FOR	1		FRONT BEARING REMOVAL
14		HLX5	150 746 48	GAGE	1		NO--GO GAGE FOR SEAL GROOVE
15		HLX5	550 103 96	PUNCH	1		ASSEMBLY OF NEEDLE BEARINGS, HLX5
							Ø 19mm, Ø 30mm, BASIC
16		HLX5	550 067 40	MOUNTING	1		SUPPORT INCL. PARTS 53, 54
17		HLX5	449 701 50	LIFTING EYE	2		M24 C15 DIN 580
18		HLX5	449 697 70	LIFTING EYE	2		M16 C15 DIN 580
19		HLX5	150 678 08	PUNCH	1		FOR STABILATOR PISTON SEAL MOUNTING
20		HLX5	150 679 28	PUNCH	1		FOR STABILATOR PISTON SEALS
21		HLX5	150 680 98	PUNCH	1		STABILATOR PISTON SEAL MOUNTING
22		HLX5	550 058 64	STAND STAND	1		FOR ACCUMULATOR

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
23		HLX5	152 501 38	OPENER	1		ACCUMULATOR
24		HLX5	096 876 58	STAND	1		FOR ACCUMULATOR
25		HLX5	152 098 78	TOOL	1		FOR ACCUMULATOR BOTTOM
26		HLX5	090 300 38	CHECKING GAUGE HP	1		(0--100 bar)
27		HLX5	090 845 48	CHECKING GAUGE LP	1		(0--10 bar)
28		HLX5	153 936 18	FILL. DEVICE FOR HYDR--ACCUMUL.	1		INCL. PART 51
29		HLX5	833 710 99	SEALS REMOVING SET	1		SEALS
30		HLX5	550 067 39	SPECIAL TOOLS	1		INCL. PARTS
		HLX5	870 492 19	TORQUE WRENCH	1		
		HLX5	870 495 09	SOCKET 24MM	1		
		HLX5	870 493 49	SOCKET 19MM	1		
		HLX5	880 976 79	OPEN END SOCKET	1		
		HLX5	870 504 19	HAMMER	1		
		HLX5	870 498 89	SPANNER	1		
		HLX5	870 499 09	WRENCH	1		
		HLX5	870 510 19	EXTENSION BAR	1		
		HLX5	836 746 09	SOCKET KLM 7	1		
		HLX5	836 747 39	SOCKET KLM 8	1		
		HLX5	870 511 49	ADAPTER	1		
31		HLX5	886 364 09	END SOCKET	1		REAR MOUNTING TO
32		HLX5	872 445 79	SOCKET 46MM	1		46mm 3/4"
34		HLX5	550 435 36	PUNCH	1		FOR HLX5
35		HLX5	550 435 37	PUNCH	1		FOR HLX5
36		HLX5	550 416 59	FLANGE	1		FOR HLX5, special tools
37		HLX5	550 398 97	GREASE NIPPLE	1		FOR HLX5T
38		HLX5	550 439 65	FLANGE	1		FOR HLX5T, special tools
39		HLX5	550 439 66	SCREW	1		FOR HLX5T, special tools
40		HLX5	550 398 70	PUNCH	1		FOR HLX5
41		HLX5	550 098 84	STOPPER	1		LIMITER OF ASSEMBLY DEPTH
42		HLX5	550 099 24	PUNCH	1		REMOVAL OF REAR BEARING, HLX5
43		HLX5	550 099 31	PUNCH	1		REMOVAL AND ASSEMBLY OF CHUCK, HLX5
51		HLX5	152 280 08	HOSE ASSY FOR FILLING DEVICE	1		
52		HLX5	869 598 69	PRESSURE SEAL	2		FOR PARTS 26, 27
53		HLX5	550 057 27	ASSEMBLY STAND	1		STAND FOR ROCK DRILL HLX5
54		HLX5	098 067 79	STAND	1		
55		HLX5	550 056 18	ROD	1		
56		HLX5	550 056 17	PUNCH	1		
57		HLX5	550 479 73	SPECIAL TOOL KIT FOR THE SITE	1		INCL. 22, 23, 24, 25, 26, 27, 28, 30, 31, 52
		HLX5	770 156 48	ACCUMULATOR FILLING CASE A.4			
		HLX5		MALLETTE DE GONFLAGE ACCUMULATEURS			
1		HLX5	770 156 49	HP FITTING BENT	1		ADAPTEUR COUDE HP
2		HLX5	770 156 50	INFLATING HOSE	1		FLEX DE GONFFLAGE
3		HLX5	770 156 51	SEAL KIT	1		KIT DE JOINT
4		HLX5	770 156 52	INFLATING FITTING M28X1	1		RACCORD GONFFLAGE M28X1
5		HLX5	770 156 54	HOSE	1		FLEXIBLE
6		HLX5	770 156 56	FITTING	1		ADAPTEUR

