

COP 1132 Drifter Parts for Atlas Copco

COP1132

| No | Crawler Drill | Drfter | Part Number | Part Name | Q'ty | Unit Price | Remarks |
|----|---------------|----------|--------------|-----------------|------|------------|---------|
| | | | | | | | |
| | | COP 1132 | 3115 9165 90 | SEAL KIT | 1 | | |
| 1 | | COP 1132 | 3115 3246 00 | FRONT PART | 1 | | |
| 2 | | COP 1132 | 3115 3251 00 | GUIDE | 1 | | |
| 3 | | COP 1132 | 3115 3252 00 | SEAL HOLDER | 1 | | |
| 4 | | COP 1132 | 3115 3253 00 | FLUSHING HEAD | 1 | | |
| 5 | | COP 1132 | 3115 3254 00 | WASHER | 1 | | |
| 6 | | COP 1132 | 3115 3255 00 | STOP RING | 1 | | |
| 7 | | COP 1132 | 3115 3256 00 | FLUSHING ADAPT. | 1 | | |
| 8 | | COP 1132 | 0663 2100 61 | O-RING | 1 | | |
| 9 | | COP 1132 | 0663 2101 68 | O-RING | 3 | | |
| 11 | | COP 1132 | 0663 6140 01 | O-RING | 1 | | |
| 12 | | COP 1132 | 0663 6135 01 | O-RING | 1 | | |
| 13 | | COP 1132 | 0663 2114 00 | O-RING | 2 | | |
| 14 | | COP 1132 | 3115 3282 01 | WIPER | 2 | | |
| 15 | | COP 1132 | 3115 3283 01 | CUP SEAL | 3 | | |
| 16 | | COP 1132 | 0108 3353 00 | SPRING PIN | 1 | | |
| | | | | | | | |
| | | COP 1132 | 0663 6149 00 | O-RING | 1 | | |
| 1 | | COP 1132 | 0663 2100 61 | O-RING | 1 | | |
| 2 | | COP 1132 | 0663 2101 68 | O-RING | 3 | | |
| 4 | | COP 1132 | 0663 6140 01 | O-RING | 1 | | |
| 5 | | COP 1132 | 0663 6135 01 | O-RING | 1 | | |
| 6 | | COP 1132 | 0663 2114 00 | O-RING | 2 | | |
| 7 | | COP 1132 | 3115 3282 01 | WIPER | 2 | | |
| 8 | | COP 1132 | 3115 3283 01 | CUP SEAL | 3 | | |
| | | | | | | | |
| 1 | | COP 1132 | 3115 3248 00 | CYLINDER | 1 | | |
| 2 | | COP 1132 | 3115 3270 00 | LINER | 1 | | |
| 3 | | COP 1132 | 3115 3271 00 | PISTON GUIDE | 1 | | |
| 4 | | COP 1132 | 3115 3272 00 | SEAL HOUSING | 1 | | |
| 5 | | COP 1132 | 3115 3276 00 | PISTON | 1 | | |
| 6 | | COP 1132 | 3115 3274 00 | PISTON GUIDE | 1 | | |
| 7 | | COP 1132 | 3115 3273 00 | GUIDE HOUSING | 1 | | |
| 8 | | COP 1132 | 3115 3275 00 | SEAL HOUSING | 1 | | |
| 9 | | COP 1132 | 3115 3277 00 | VALVE PISTON | 1 | | |
| 10 | | COP 1132 | 3115 3278 00 | VALVE COVER | 1 | | |
| 11 | | COP 1132 | 3115 3279 00 | VALVE COVER | 1 | | |
| 12 | | COP 1132 | 3115 3286 05 | SEAL KIT | 1 | | |
| 13 | | COP 1132 | 3115 3286 02 | SEAL KIT | 1 | | |
| 14 | | COP 1132 | 3115 3288 05 | WIPER | 1 | | |
| 15 | | COP 1132 | 3115 3288 02 | WIPER | 1 | | |

Driven by our values :

Honesty, Integrity, Accountability, Quality and Service Excellence!!!!

ERG Korea CO., Ltd.

| No | Crawler Drill | Drfter | Part Number | Part Name | Q'ty | Unit Price | Remarks |
|----|---------------|----------|--------------|------------------------|------|------------|---------|
| 16 | | COP 1132 | 0663 2135 01 | O-RING | 1 | | |
| 17 | | COP 1132 | 0663 2101 67 | O-RING | 2 | | |
| 18 | | COP 1132 | 0663 9078 01 | O-RING | 1 | | |
| 19 | | COP 1132 | 3115 3289 01 | SEAL RING | 1 | | |
| 20 | | COP 1132 | 3115 3048 00 | SEAL RING | 1 | | |
| 21 | | COP 1132 | 3115 3280 00 | WEAR PLUG | 1 | | |
| 22 | | COP 1132 | 0102 0408 00 | PIN | 2 | | |
| 23 | | COP 1132 | 0147 1476 03 | SCREW, HEX HEAD | 4 | | |
| 30 | | COP 1132 | | CYLINDER | 1 | | |
| 31 | | COP 1132 | 0259 0086 00 | THREAD INSERT | 2 | | |
| 32 | | COP 1132 | 0259 0084 00 | THREAD INSERT | 4 | | |
| 33 | | COP 1132 | 3115 1825 00 | PLUG | 2 | | |
| 34 | | COP 1132 | 3115 1460 00 | PLUG | 1 | | |
| | | | | | | | |
| 1 | | COP 1132 | 3115 3247 00 | GEAR HOUSING | 1 | | |
| 2 | | COP 1132 | 3115 3257 00 | BUSHING | 1 | | |
| 3 | | COP 1132 | 0335 3501 32 | LOCK RING | 1 | | |
| 4 | | COP 1132 | 3115 3258 00 | LINER | 1 | | |
| 5 | | COP 1132 | 3115 3259 01 | DAMPING PISTON | 1 | | |
| | | COP 1132 | 3115 3259 00 | DAMPING PISTON | 1 | | |
| 6 | | COP 1132 | 3115 3260 01 | ROT. CH. BUSHING | 1 | | |
| | | COP 1132 | 3115 3260 00 | ROTATION CHUCK BUSHING | 1 | | |
| 7 | | COP 1132 | 3115 3261 00 | BACK-UP RING | 1 | | |
| 8 | | COP 1132 | 0509 0121 12 | ROLLER BEARING | 1 | | |
| 9 | | COP 1132 | 0509 0221 00 | ROLLER BEARING | 1 | | |
| 10 | | COP 1132 | 3115 3262 00 | ROT.CHUCK | 1 | | |
| 11 | | COP 1132 | 3115 3263 00 | COVER | 1 | | |
| 12 | | COP 1132 | 3115 3264 00 | DRIVER | 1 | | |
| 13 | | COP 1132 | 3115 3268 00 | VALVE CONE | 1 | | |
| 14 | | COP 1132 | 3115 3269 00 | VALVE SEAT | 1 | | |
| 15 | | COP 1132 | 3115 3265 00 | BACK-UP RING | 1 | | |
| 16 | | COP 1132 | 0516 4100 26 | INNER RING | 1 | | |
| 17 | | COP 1132 | 0516 4100 25 | INNER RING | 1 | | |
| 18 | | COP 1132 | 0516 4047 00 | NEEDLE BEARING | 1 | | |
| 19 | | COP 1132 | 0516 4000 25 | NEEDLE BEARING | 1 | | |
| 20 | | COP 1132 | 3115 3266 00 | GEAR WHEEL | 1 | | |
| 22 | | COP 1132 | 0147 1363 03 | SCREVV, HEX HEAD | 2 | | |
| 23 | | COP 1132 | 0663 6140 01 | O-RING | 1 | | |
| 24 | | COP 1132 | 0663 2105 76 | O-RING | 1 | | |
| 25 | | COP 1132 | 0663 2101 68 | O-RING | 1 | | |
| 26 | | COP 1132 | 9125 6216 00 | O-RING | 1 | | |
| 27 | | COP 1132 | 0663 2118 01 | O-RING | 1 | | |
| 28 | | COP 1132 | 0663 2135 01 | O-RING | 1 | | |
| 29 | | COP 1132 | 3115 3284 01 | SEAL KIT | 1 | | |
| 30 | | COP 1132 | 3115 3284 02 | SEAL KIT | 1 | | |
| 31 | | COP 1132 | 0666 6000 48 | RADIAL LIP SEAL | 1 | | |
| 32 | | COP 1132 | 0666 7188 01 | RADIAL LIP SEAL | 1 | | |

| No | Crawler Drill | Drfter | Part Number | Part Name | Q'ty | Unit Price | Remarks |
|-----|---------------|----------|--------------|-------------------|------|------------|---------|
| 33 | | COP 1132 | 3115 3048 00 | SEAL RING | 1 | | |
| 34 | | COP 1132 | 3115 3290 02 | SEAL RING | 2 | | |
| 35 | | COP 1132 | 0665 0900 14 | SEAL RING | 2 | | |
| 36 | | COP 1132 | 0102 0408 00 | PIN | 1 | | |
| 37 | | COP 1132 | 0544 2162 00 | GREASE NIPPLE | 1 | | |
| 38 | | COP 1132 | 0661 1014 00 | SEALWASHER | 4 | | |
| 39 | | COP 1132 | 0686 4201 03 | PLUG | 4 | | |
| 40 | | COP 1132 | | GEAR HOUSING | 1 | | |
| 41 | | COP 1132 | 0259 2073 03 | THREAD INSERT | 2 | | |
| 42 | | COP 1132 | 0259 0086 00 | THREAD INSERT | 6 | | |
| 43 | | COP 1132 | 0196 1318 00 | SET SCREW | 1 | | |
| 44 | | COP 1132 | 3115 1746 06 | NOZZLE | 2 | | |
| 261 | | COP 1132 | 3115 3621 00 | MOTOR BRACKET | 1 | | |
| 262 | | COP 1132 | 0196 1318 00 | SET SCREW | 4 | | |
| 263 | | COP 1132 | 0663 2114 00 | O-RING | 2 | | |
| | | | | | | | |
| 1 | | COP 1132 | 3115 3251 00 | GUIDE | 1 | | |
| 2 | | COP 1132 | 3115 3255 00 | STOP RING | 1 | | |
| 3 | | COP 1132 | 0108 3353 00 | SPRING PIN | 1 | | |
| 4 | | COP 1132 | 3115 1324 00 | DIAPHRAGM | 2 | | |
| | | | 3115 3593 00 | DIAPHRAGM NEW | 1 | | |
| 14 | | | 3115 3594 80 | ACCUMULATOR - NEW | | | |
| 5 | | COP 1132 | 3115 0262 00 | VALVE | 2 | | |
| 6 | | COP 1132 | 3115 3597 00 | LABEL SET | 2 | | |
| 8 | | COP 1132 | 3310 4076 00 | CAP | 2 | | |
| 9 | | COP 1132 | 3115 3281 00 | SIDE BOLT | 2 | | |
| 10 | | COP 1132 | 3115 3315 00 | DOME NUT | 2 | | |
| 11 | | COP 1132 | 3115 3260 01 | ROT. CH. BUSHING | 1 | | |
| 14 | | COP 1132 | 3115 3264 00 | DRIVER | 1 | | |
| 19 | | COP 1132 | 0544 2162 00 | GREASE NIPPLE | 1 | | |
| 20 | | COP 1132 | 0102 0408 00 | PIN | 1 | | |
| 21 | | COP 1132 | 3115 9162 90 | SEAL KIT | 1 | | |
| 22 | | COP 1132 | 3115 3226 90 | SEAL KIT | 1 | | |
| | | COP 1132 | 3115 9163 90 | SEAL KIT | 1 | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |