

# COP 1238 Drifter Parts for Atlas Copco

Atlas Copco

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
1		COP 1238	*	front head	<b>3115 1362 00</b>		<b>10.20kg</b>
2		COP 1238	3115 0286 00	dome nut			0.26kg
3		COP 1238	3115 0287 00	washer			0.04
4		COP 1238	0147 1401 03	screw			
5		COP 1238	<b>3115 1938 00</b>	connection plate			1.54kg
6		COP 1238	0665 1000 12	cup seal			
7		COP 1238	0661 1049 00	seal washer			
8		COP 1238	3115 1629 00	flushing house 3/4			0.88
9		COP 1238	3115 1457 00	side bolt			0.82kg
		COP 1238	3115 1364 80	cover,compl			5kg
10		COP 1238	*	cover	3115 1364 00		
11		COP 1238	0666 7190 01	seal ring			0.06kg
12		COP 1238	0335 3576 00	lock ring			0.02
13		COP 1238	<b>0102 0473 00</b>	cylindrical pin			
14		COP 1238	0663 6151 00 **	o-ring			
15		COP 1238	3115 0297 01	shim 0.10mm			0.1
15		COP 1238	3115 0297 02	shim 0.15			0.15
15		COP 1238	3115 0297 03	shim 0.5			0.5
16		COP 1238	<b>0509 0223 00</b>	roller bearing 32018XQ			1.8kg
17		COP 1238	3115 0285 00	side bolt	3115 2113 00		
18		COP 1238	7804 3590 03	shank(t38)			
19		COP 1238	3115 1582 00	driver			1.66kg
		COP 1238	3115 1732 80	rotation chuck			4.44kg
20		COP 1238	*	rotation chuck			
21		COP 1238	3115 1733 00	bushing	3115 1881 00		0.18kg
22		COP 1238	0509 0221 00	roller bearing 32016XQ			1.3kg
		COP 1238	<b>3115 1365 80</b>	gear housing			
23		COP 1238	*	gear housing			
24		COP 1238	0686 3101 00	plug			
25		COP 1238	0544 2162 00	lubricating nipple			
26		COP 1238	0666 7188 01	seal ring			0.04
27		COP 1238	0335 3572 00	lock ring			0.01
28		COP 1238	<b>3115 0273 00</b>	washer			0.02
29		COP 1238	0663 2120 00**	o-ring			
30		COP 1238	<b>0663 6146 00**</b>	o-ring			
31		COP 1238	3115 1735 00	rotation chuck bushing			
31		COP 1238	3115 1734 00	rotation chuck bushing			
31		COP 1238	3115 2200 00	rotation chuck bushing			1.44kg
		COP 1238	3115 0821 80	shaft,compl.	2.1kg		27,29,30,31,26,32 set
32		COP 1238	3115 0821 00	shaft			1.54kg
33		COP 1238	<b>0516 1504 01</b>	needle bearing			0.06
34		COP 1238	3115 0823 00	washer			0.02kg

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
35		COP 1238	0516 1538 00	needle bearing			0.1
36		COP 1238	3115 0824 00	sleeve			<b>0.2kg</b>
37		COP 1238	0667 1206 00	cup seal			
38		COP 1238	3115 0825 00	guide sleeve	3115 2742 00		0.3kg
39		COP 1238	3115 0274 00	gear			0.64kg
40		COP 1238	0663 2133 01**	o-ring			
41		COP 1238	<b>3115 1353 00</b>	damping piston			2.72kg
42		COP 1238	B	set of seals			
43		COP 1238	B	set of seals			
		COP 1238	3115 1366 00	intermediate part			
			<b>3115 2857 00</b>	intermediate part			
44		COP 1238		intermediate part			
		COP 1238	0259 2061 00	thread insert			
		COP 1238					
45		COP 1238	3115 1746 03	nozzle			
46		COP 1238	3115 1458 00	connection plate	3115 3455 00		
47		COP 1238	0211 1401 00	screw			
48		COP 1238	0663 2126 01**	o-ring			
49		COP 1238	0686 9110 00	protective plug			
50		COP 1238	3115 1763 82	<b>diaphragm accumulator</b> 3115 2696 80	3115 3511 81		4.04KG
51		COP 1238	0147 1483 03	screw			
		COP 1238	3115 1103 80	seal housing			0.40kg
		COP 1238	3115 1185 80	seal housing			
52		COP 1238	*	seal housing			
52		COP 1238	*	seal housing			
53		COP 1238	3115 0970 00	set of seals			
54		COP 1238	0663 6136 00**	o-ring			
55		COP 1238	0663 6142 00**	o-ring			
56		COP 1238	3115 1671 00	piston guide front	3115 5050 01		0.28KG
56		COP 1238	3115 1674 00	piston guide front			
57		COP 1238	0663 6134 01**	o-ring			
58		COP 1238	<b>3115 1823 00</b>	valve piston			0.38KG
59		COP 1238	3115 1418 00	valve cover			
59		COP 1238	3115 1529 00	valve cover			
60		COP 1238	3115 1418 00	valve cover			
60		COP 1238	3115 1529 00	valve cover			
60		COP 1238	3115 1558 00	valve cover			
62		COP 1238	0147 1438 03	screw			0.06
63		COP 1238	0147 1487 03	screw			
64		COP 1238	3115 1697 00	seal sasher			
65		COP 1238	<b>3115 1530 00</b>	regulating plug			
65		COP 1238	3115 1455 00	regulating plug			0.1kg
66		COP 1238	3115 1692 00	dome nut			0.06
		COP 1238	3115 1367 80	cylinder			
67		COP 1238	*	cylinder			
68		COP 1238	3115 1460 00	pipe puge			
		COP 1238	0259 0011 00	thread insert			

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
		COP 1238	0259 0311 00	thread insert			
69		COP 1238	3115 0276 00	guide			
70		COP 1238	3115 1165 00	stud			0.02kg
72		COP 1238	3115 0277 00	coupling			0.38kg
73		COP 1238	0335 2130 00	circlip			
74		COP 1238	<b>3115 1010 80</b>	hydraulic motor	oms-100		10.5kg
75		COP 1238	3115 1454 00	nut			
76		COP 1238	0663 9051 00**	o-ring			
77		COP 1238	3115 1490 00	piston(HF)			
77		COP 1238	3115 1173 00	piston(LE)			4.92KG
77		COP 1238	3115 0288 00	piston(ME)			4.92KG
77		COP 1238	3115 1567 00	piston(HE)			
			3115 1651 00	piston			4kg
78		COP 1238	0663 6137 00**	o-ring			
79		COP 1238	3115 1680 00	piston guide rear			0.34KG
79		COP 1238	3115 1673 00	piston guide rear			
79		COP 1238	3115 1672 00	piston guide rear			0.32kg
		COP 1238	3115 1104 80	seal housing	3115 2773 80		0.42kg
		COP 1238	3115 1186 80	seal housing			
		COP 1238	3115 1154 80	seal housing			
		COP 1238	3115 1731 80	seal housing			
80		COP 1238	*	seal housing			
80		COP 1238	*	seal housing			
80		COP 1238	*	seal housing			
80		COP 1238	*	seal housing			
81		COP 1238	3115 0844 00	set of seals			
81		COP 1238		set of seals			
82		COP 1238	0663 6135 00**	o-ring			
83		COP 1238	3115 1368 00	back head [me/			
83		COP 1238	3115 1568 00	back head			
84		COP 1238	0291 1180 02	lock nut			0.06kg
85		COP 1238	3176 6512 00	nipple			
86		COP 1238	3176 5313 00	cap			
87		COP 1238	3176 6514 00	nipple			
88		COP 1238	3715 0597 00	cap			
89		COP 1238	3115 1698 00	seal washer			
		COP 1238	3115 9150 91	o-ring set			0.08kg
		COP 1238	3115 9150 93	o-ring set			
1		COP 1238	3115 1362 00	front head			10.20kg
2		COP 1238	3115 1436 00	guide			1.1kg
3		COP 1238	0667 3194 00	cup seal	3115 3364 00		3115 2333 0
4		COP 1238	0663 2145 01**	o-ring			
5		COP 1238	3115 1432 00	flushing head	3115 2078 00		4.2kg
6		COP 1238	3115 1434 00	stop ring			1.4kg
7		COP 1238	3115 1435 00	guide			1.08KG
8		COP 1238	<b>0667 3215 00</b>	cup seal			0.02
9		COP 1238	3115 1437 00	flushing head	3115 2079 00		4.5kg

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
10		COP 1238	3115 1476 00	cup seal	3115 2582 00		
		COP 1238	3115 1841 80	stop ring			1.5kg
11		COP 1238	*	stop ring			
12		COP 1238	0663 6142 00**	o-ring			
18		COP 1238	7804 3590 03	shank adapter R38H			
18		COP 1238	7304 3591 01	shank adapter T38			
18		COP 1238	7305 3591 01	shank adaper T45			
		COP 1238					
1		COP 1238	3115 1362 00	front head			10.20kg
2		COP 1238	3115 1436 00	guide			1.1kg
3		COP 1238	0667 3194 00	cup seal			3115 2333 0
4		COP 1238	0663 2145 01**	o-ring			
5		COP 1238	<b>3115 1432 00</b>	flushing head	3115 2078 00		4.2kg
6		COP 1238	3115 1557 00	stop ring			
18		COP 1238	7803 3590 03	shank adapter R32D			
18		COP 1238	7803 3593 01	shank adaper R32E			
18		COP 1238	7804 3590 03	shank adapter R32D			
18		COP 1238	7304 3590 03	shank adapter T38D			
18		COP 1238	7304 3593 01	shank adapter T38E			
1		COP 1238	3115 1362 00	front head			10.20kg
2		COP 1238	3115 1436 00	guide			1.1kg
3		COP 1238	0667 3194 00	cup seal			
4		COP 1238	0663 2145 01**	o-ring			
5		COP 1238	3115 1432 00	flushing head	3115 2078 00		4.2kg
6		COP 1238	3115 1434 00	stop ring			1.4kg
7		COP 1238	3115 1435 00	guide			1.08KG
8		COP 1238	0667 3215 00	cup seal			0.02
9		COP 1238	3115 1437 00	flushing head			
10		COP 1238	3115 1476 0	cup seal			
		COP 1238	3115 1841 80	stop ring			1.5kg
11		COP 1238	*	stop ring			
12		COP 1238	0663 6142 00**	o-ring			
18		COP 1238	7803 3591 01	shank adaper R32			
18		COP 1238	7804 3590 03	shank adapter R38			
18		COP 1238	7304 3591 01	shank adapter T38			
18		COP 1238	7305 3591 01	shank adapter T45			
		COP 1238					
1		COP 1238	3115 1362 00	front head			10.20kg
2		COP 1238	3115 1436 00	guide			1.1kg
3		COP 1238	0667 3194 00	cup seal	3115 3364 00		3115 2333 0
4		COP 1238	0663 2145 01**	o-ring			
5		COP 1238	3115 1432 00	flushing head	3115 2078 00		4.2kg
6		COP 1238	3115 1434 00	stop ring			1.4kg
7		COP 1238	3115 1435 00	guide			1.08KG
8		COP 1238	0667 3215 00	cup seal			
9		COP 1238	3115 1437 00	flushing head			4.5kg
10		COP 1238	3115 1476 00	cup seal			

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
		COP 1238	3115 1841 80	stop ring			1.5kg
11		COP 1238	*	stop ring			
12		COP 1238	0663 6142 00**	o-ring			
18		COP 1238	7804 3590 03	shank adapter R32			
18		COP 1238	7803 3593 01	shank adapter R32E			
18		COP 1238	7804 3594 01	shank adapter R38H			
18		COP 1238	7304 3590 03	shank adapter T38D			
18		COP 1238	7304 3591 01	shank adapter T38			L500
18		COP 1238	7304 3593 01	shank adapter T38E			
18		COP 1238	7305 3591 01	shank adapter T45			
18		COP 1238	7305 3593 01	shank adapter T45E			
		COP 1238					
		COP 1238	3115 1010 93	set of seals			
		COP 1238	3115 1010 80	hydraulic motor	oms100		10.5kg
		COP 1238	3115 1010 81	hydraulic motor	oms160		11kg
		COP 1238	3115 1010 82	hydraulic motor	oms80		
		COP 1238	3115 1010 83	hydraulic motor	oms315		11.5kg
		COP 1238					
1		COP 1238	3115 1010 47	bearing housing			
2		COP 1238	**	seal ring			
3		COP 1238	3115 1010 48	splined shaft			
4		COP 1238	**	seal ring			
5		COP 1238	**	o-ring			
6		COP 1238	3115 1010 42	intermdiste plate			
7		COP 1238	3115 1010 27	drain plug			
8		COP 1238	3115 1010 28	washer			
9		COP 1238	3115 1010 32	cardan shaft			
9		COP 1238	3115 1010 07	cardan shaft			
9		COP 1238	3115 1010 29	cardan shaft			
9		COP 1238	3115 1010 49	cardan shaft			
10		COP 1238	**	o-ring			
11		COP 1238	3115 1010 45	cog wheel set			
11		COP 1238	3115 1010 43	cog wheel set			
11		COP 1238	3115 1010 50	cog wheel set			
11		COP 1238	3115 1010 51	cog wheel set			
12		COP 1238	3115 1010 10	guide pin			
13		COP 1238	3115 1010 12	valve drive			
14		COP 1238	3115 1010 13	channel plate			
15		COP 1238	3115 1010 14	disc valve			
16		COP 1238	3115 1010 15	balance plate			
17		COP 1238	3115 1010 16	guide pin			
18		COP 1238	**	o-ring			
19		COP 1238	**	o-ring			
20		COP 1238	3115 1010 19	spacer pin			
21		COP 1238	3115 1010 20	spring ring			
22		COP 1238	3115 1010 21	valve housing			
23		COP 1238	**	seal plug			

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
24		COP 1238	3115 1010 46	screw			
24		COP 1238	3115 1010 44	screw			
24		COP 1238	3115 1010 52	screw			
24		COP 1238	3115 1010 53	screw			
25		COP 1238	**	seal ring			
26		COP 1238	3115 1010 23	check valve ball			
27		COP 1238	3115 1010 24	check valve spring			
28		COP 1238	3115 1010 25	check valve plug			
		COP 1238					
		COP 1238	3115 1763 82	ACCUMULATOR	3115 2696 80set		4.04KG
1		COP 1238	3115 1876 00	housing			
2		COP 1238	3115 1822 00	diaphragm			0.04kg
3		COP 1238	3115 0263 00	plug			
4		COP 1238	0663 6121 00**	o-ring			
5		COP 1238	3115 1763 00	cover			
		COP 1238	3115 0262 00	valve			0.04kg
6		COP 1238	*	valve			
7		COP 1238	3310 4076 00	cap			
8		COP 1238	0663 9056 00**	o-ring			
		COP 1238	<b>3115 9150 95</b>	<b>seal kit / 400 hours rebuild kit</b>			0.56
		COP 1238	<b>3115 9150 91</b>	<b>o-ring set</b>	Incl. gasket		0.08
42,43		COP 1238	3115 1880 90	sealing set			0.06
			3115 0288 91	repair kit			31kg
		COP 1238	3115 1732 81	Rotation chuck, complete 1 set	3115 1732 00		4.44kg
		COP 1238		Diaphragm			
		COP 1238					
			3115 2196 00				
		COP1238 ME	3115 1436 90	Rebuild kit for COP 1238 ME-T38			
		COP1238 ME	3128 0458 18	slider bar			6000*450*420