

Furukawa HD150 Drifter Parts

Furukawa HD150

No	Crawler Drill Model	Drifter Model	Part Number	Part Name	Q'ty	Unit Price	Remarks
		HD150	000500-100060	Seal, Step			
1		HD150	000500-100071	Ring, gride			
2		HD150	000500-100090	Seal, Step			
3		HD150	000500-100101	Ring, gride			
4		HD150	000500-100111	Valve			
5		HD150	000500-100122	Plug			
6		HD150	HB30G-10121	Bush			
7		HD150	000500-110010	Piston			
8		HD150	000500-200020	Bearing, Plain			
9		HD150	000500-200030	Driver, Chuck			
10		HD150	000500-200040	Bearing, Plain			
11		HD150	000500-200050	Bush, Chuck Driver			
12		HD150	000500-200060	Gear, Driver			
13		HD150	000500-200070	Chuck			
14		HD150	280040-06014	Bearing, Ball			
15		HD150	HD150-02105	Bearing, Plain			
16		HD150	HD150-02208	Bush, Front			
17		HD150	085610-40559	U-Packing			
18		HD150	000500-220050	Washer, Thrust			
19		HD150	HIA175-02315	Rubber, Protect			
20		HD150	HD190-03601	Bolt			
21		HD150	000500-360010	Bolt, Thruhg			
22		HD150	HD190-03603	Nut			
23		HD150	000500-360020	Bolt			
24		HD150	000500-600010	Motor, Orbit			
25		HD150	000500-150031	Ring, gride			
26		HD150	000500-150041	Ring, gride			
27		HD150	000500-150051	Piston, Damping			
28		HD150	000500-150061	Ring, gride			
29		HD150	000500-150071	Ring, gride			
30		HD150	000500-150082	Piston, Pushing			
31		HD150	900500-700010	Accumulator Ass'y			
32		HD150	007320-70104	Diaphragm			
33		HD150	083301-020320	Plate, Slide			
34		HD150	083301-020400	Guide, Wire			
35		HD150	GH160-00203	Roller, Bearing			
36		HD150	083301-030480	Plate, Guide			
37		HD150	083301-030530	Plate, Slide			
38		HD150	284040-00213	Roller, Bearing			
39		HD150	GH165-00507	Metal Bush			
40		HD150	083301-060160	Centralizer Ass'y			

No	Crawler Drill Model	Drifter Model	Part Number	Part Name	Q'ty	Unit Price	Remarks
41		HD150	GH165-00523	Linner, Sub centralizer			
42		HD150	083301-070140	Body, Sub centralizer			
43		HD150	ZN130-C35101	Pump, PV			
44		HD150	929640-010010	A4V Pump			
45		HD150	929640-020010	A6V Pump			
46		HD150	929640-030010	Gear Pump (28)			
47		HD150	ZN510-C20133	Water Booster Pump			
48		HD150					
49		HD150	HD150-02208	Front Bush			
50		HD150	HD150-02211	Plain Bearing (B)			
51		HD150	HD150-02104	Rod Retainer			
52		HD150	HD150-02003	Plain Bearing (A)			
53		HD150	HD150-02102	Plain Bearing (B)			
54		HD150	HD150-02007	Chuck			
55		HD150	HD150-01102	Piston (B)			
56		HD150	HD150-02005	Chuck Driver (A)			
57		HD150	HD150-02004	Thrust Bearing			
58		HD150	HD150-02008	Drive Gear (A)			
59		HD150	HD150-02006	Chuck Driver Bush (A)			
60		HD150	HD150-02210	Bearing Holder			
61		HD150	HD150-01305	Valve Plug (B)			
62		HD150	HD150-01301	Valve			
63		HD150	HD150-01303	Bush (RA)			
64		HD150	HD150-97001	Accumulator Ass'y			
65		HD150	280100-06208	Ball Bearing			
66		HD150	280100-06307	Ball Bearing			
67		HD150	007210-60001	Orbit Motor			
68		HD150	085610-40559	U Packing (Drifter)			
69		HD150	HD350-01007	U Packing (Drifter)			
70		HD150	HD350-01014	Dust Seal (Drifter)			
71		HD150	008110-10010	U Packing (Drifter)			
72		HD150	008110-10011	Dust Seal (Drifter)			
73		HD150	HD150-99104	Seal Kit HD 150			
74		HD150	GH165-90503	Sub Centerlizer Ass'y			
75		HD150	GH165-00146	Wire Rope (33R)			
76		HD150	GH165-00149	Wire Rope (F-9)			
77		HD150	GH165-00507	Metal Bush			
78		HD150	GH165-90503	Center Lizer Ass'y			
79		HD150	ZN500-50102	Libricator Ass'y			
80		HD150	933100-04001	Rotary Ass'y			
81		HD150	ZN1520-C40601	Pressure guage (60MPa)			
82		HD150	024106-02004	Fuse Box			
83		HD150	GH165-00421	Seal Kit/feed Cylinder			
84		HD150	985515-21046	Seal Kit/boom lift cylinder			
85		HD150	985511-22011	Seal Kit/boom swing cylinder			
86		HD150	985513-21012	Seal Kit/guide tilt cylinder			
87		HD150	985508-21028	Seal Kit/guide swing cylinder			

No	Crawler Drill Model	Drifter Model	Part Number	Part Name	Q'ty	Unit Price	Remarks
88		HD150	985509-21045	Seal Kit/guide dump cylinder			
89		HD150	985507-21018	Seal Kit/guide slide cylinder			
90		HD150	985513-61601	Seal Kit/cage boom lift cylinder			
91		HD150	985508-63602	Seal Kit/cage boom slide cylinder			
92		HD150	985510-61606	Seal Kit/cage boom swing cylinder			
93		HD150	985508-61601	Seal Kit/cage tilt/tilt master cylinder			
94		HD150	985508-61602	Seal Kit/Steering cylinder			
95		HD150	ZN5720-20610	Seal Kit/deck lift cylinder			
96		HD150	ZN810-C20179	Seal Kit/outrogger cylinder			
97		HD150	ZN600-C12002	Control box (CO) ass'y			
98		HD150	ZN600-C12003	Control box (W) ass'y			
99		HD150	GH165-00142	Food Pat			
100		HD150	081600-01007	19 Hose Adjuster			
101		HD150	081600-01008	12House Adjuster			
102		HD150	GH165-00205	Roller Bearing			
103		HD150	GH75-10203	Guide Plate			
104		HD150	GH165-00228	Guide Plate			
105		HD150	GH165-00224	Inner Wheel			
106		HD150	GH165-00225	Wheel			
107		HD150	271070-10014	Oil Seal			
108		HD150	ZN5730-C40201	A6V Motor			
109		HD150	ZN5730-10423	Lever COMP			
110		HD150	ZN5730-C40102	A4V Pump			
111		HD150	ZN120-C41203	3 Unit Gear Pump (50 HZ)			
112		HD150	ZN120-C41215	4 Unit Gear Pump (50 HZ)			
113		HD150	ZN5730-30117	Gear Pump			
114		HD150	922004-07033	Oil Supply Pump			
115		HD150	ZN3000-40103	Strainer			
116		HD150	ZN 1000-90201	Strainer			
117		HD150	ZN2000-20436	Element (10 micron)			
118		HD150	ZN1000-C45370	Pressure gauge (350 K)			
119		HD150	ZN1000-C45310	Pressure gauge (150 K)			
120		HD150	ZN510-C10301	Pressure gauge (35 K)			
121		HD150	ZN250-10110	M-100 Element			
122		HD150	ZN5730-30132	L O Filter			
123		HD150	ZN5730-30133	Oil Filter Element			
124		HD150	ZN5730-30134	F.O Filter			
125		HD150	ZN510-C10142	Water Booster Pump			
126		HD150	00730-70104	Diaphragm			
127		HD150	HD150-90003	Hydraulic drifter			
128		HD150	HD150-90009	Hydraulic drifter			
129		HD150	ZN5730-10923	Lever comp			
130		HD150	ZN5730-C30502	Coupling Assembly			
		HD150	GH165-00141	Bush			