

HD500 Drifter Parts

FURUKAWA

No	Crawler Drill Model	Drifter Model	Part Number	Part Name	Q'ty	Unit Price	Remarks
		HD500 C	fig.13-10 drifter				
1		HD500 C	HD500-90001	hydraulic drifter			
2		HD500 C	HD500-90004	hydraulic drifter			
3		HD500 C	HD500-01011	cylinder			
4		HD500 C	HD500-01010	seal retainer (F)			
5		HD500 C	085610-53636	U-packing			
6		HD500 C	HD500-01005	dust seal			
7		HD500 C	HD500-01013	valve housing			
8		HD500 C	HD500-01007	stroke adjuster			
9		HD500 C	HD500-01008	nut			
10		HD500 C	HD500-01009	seal washer			
11		HD500 C	HD500-01101	piston			8kg
12		HD500 C	HD500-01307	valve			
13		HD500 C	HD500-01308	valve plug			
14		HD500 C	HD500-01303	bush ®			
15		HD500 C	HD500-01304	seal retainer ®			
16		HD500 C	HD500-01305	U-packing			
17		HD500 C	HD500-01306	dust seal			
18		HD500 C	102032-12030	socket bolt			
19		HD500 C	007120-10032	bush			
20		HD500 C	102032-20075	socket bolt			
21		HD500 C	HD500-02002	front head			
22		HD500 C	HD500-02019	front head			
23		HD500 C	HD500-02003	front cover			
24		HD500 C	HD500-02004	front cap			
25		HD500 C	HD500-02005	thrust bush			HD612-02002
26		HD500 C	HD500-02006	thrust bearing			
27		HD500 C	HD500-02021	chuck			4.8kg
28		HD500 C	HD500-02020	chuck driver			17.2kg
29		HD500 C	HD500-02009	chuck driver bush			2.1kg
30		HD500 C	HD500-02010	thrust washer			
31		HD500 C	HD500-02011	front bush			1kg
32		HD500 C	HD500-02012	plain bearing (A)			HD612-02102
33		HD500 C	HD500-02013	plain bearing (B)			HD612-02003
34		HD500 C	HD500-02014	drive gear			
35		HD500 C	280100-06213	ball bearing			
36		HD500 C	102032-16030	socket bolt			
37		HD500 C	P-2093	9 hose spud			
38		HD500 C	HD500-02503	shank rod			
39		HD500 C	HD500-02506	shank rod			
40		HD500 C	HD500-06004	male adapter			
41		HD500 C	HD500-03002	back head			

No	Crawler Drill Model	Drifter Model	Part Number	Part Name	Q'ty	Unit Price	Remarks
42		HD500 C	HD500-03004	back head			
43		HD500 C	007210-30002	knock pin			
44		HD500 C	007520-10005	3/4 street union adapter			
45		HD500 C	HD500-03402	blow tube			
46		HD500 C	HD500-03403	blow tube rubber			
47		HD500 C	HD500-03404	blow connection cap			
48		HD500 C	HD500-03607	through bolt (A)			
49		HD500 C	HD500-03606	through bolt (E)			
50		HD500 C	HD500-03603	through bolt (B)			
51		HD500 C	HD500-03604	through bolt (C)			
52		HD500 C	007210-36003	through bolt nut			
53		HD500 C	001700-36102	20 nut			
54		HD500 C	HD500-06003	orbit motor			
55		HD500 C	102032-16040	socket bolt			
56		HD500 C	001201-30063	adjustable elbow			
57		HD500 C	HD500-97001	accumulator assembly			
58		HD500 C	HD500-07002	accumulator cover			
59		HD500 C	007120-70134	valve			
60		HD500 C	007010-70030	plug			
61		HD500 C	007010-70029	cap			
62		HD500 C	160011-00014	o-ring			
63		HD500 C	160011-00005	o-ring			
64		HD500 C	HD500-07012	diaphragm			0.04kg
65		HD500 C	HD500-07003	accumulator body			
66		HD500 C	160021-00065	o-ring			
67		HD500 C	262022-00065	back-up ring			
68		HD500 C	160021-00070	o-ring			
69		HD500 C	262022-00070	back-up ring			
70		HD500 C	160021-00085	o-ring			
71		HD500 C	262022-00085	back-up ring			
72		HD500 C	160021-00115	o-ring			
73		HD500 C	262022-00115	back-up ring			
74		HD500 C	160021-00100	o-ring			
75		HD500 C	262022-00100	back-up ring			
76		HD500 C	161021-00030	o-ring			
77		HD500 C	161011-00010	o-ring			
78		HD500 C	160011-00020	o-ring			
79		HD500 C	161021-00075	o-ring			
80		HD500 C	160011-00024	o-ring			
81		HD500 C	089800-90016	o-ring			
82		HD500 C	008110-10005	plug			
83		HD500 C	160011-00011	o-ring			
84		HD500 C	HD500-03609	20 helisert nut			
85		HD500 C	HD500-03608	washer			
86		HD500 C		seal kit			