

## HL(R) 438 Drifter Parts

TAMROCK

2012-03-30

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
		HL438	099 508 98	drifter			
		HL438	099 508 91	drifter			
		HL438	099 508 92	drifter			
		HL438	099 508 93	drifter			
		HL438		common parts			
1		HL438	041 105 98	diaphragm	1		
2		HL438	041 148 08	diaphragm	2		0.03kg
3		HL438	041 427 48	nut	4		0.2kg
4		HL438	041 428 78	washer	4		
5		HL438	041 433 48	orifice	1		
6		HL438	041 441 08	thrust bearing	1		0.2kg
7		HL438	041 446 38	pin	1		
8		HL438	041 454 98	bottom	1		
9		HL438	041 497 08	bearing bushing	1		
10		HL438	042 197 38	bearing bushing	1		
10		HL438	090 256 18	bearing bushing	1		0.9kg
11		HL438	042 218 18	tie rod	4		
12		HL438	042 219 48	spacer	1		1.5kg
13		HL438	042 260 48	bottom	2		
13		HL438	042 261 78	bottom	2		
14		HL438	042 263 28	distributor	1		<b>Not in stock</b>
15		HL438	042 718 58	cover	2		
16		HL438	042 733 38	accumulator H.P.assy	1		
17		HL438	042 915 28	gear housing assy	1		
18		HL438	042 920 08	rear cover	1		<b>1 used one in stock</b>
19		HL438	042 921 28	body	1		
20		HL438	047 689 68	collar	1		
21		HL438	085 256 38	chuck	1		0.8kg
22		HL438	085 318 88	orifice plate	1		
23		HL438	085 370 18	cap	2		
24		HL438	085 408 08	nut	1		
25		HL438	085 409 28	adapter	1		
26		HL438	085 435 48	gasket assy	1		
27		HL438	090 106 48	rotation axle assy	1		2.8kg
28		HL438	090 110 98	wiper assy	1		
29		HL438	090 111 18	seal assy	1		
30		HL438	090 112 48	seal assy	1		
31		HL438	090 119 38	nut	1		
32		HL438	090 120 08	connecting piece	1		1.2kg
33		HL438	090 122 58	collar	1		
34		HL438	090 314 58	elbow adaptor assy	1		
35		HL438	095 013 98	front cylinder			2kg, genuine

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
36		HL438	095 014 18	rear cylinder	1		2kg
37		HL438	095 022 78	distributor	1		<b>Not in stock</b>
38		HL438	095 023 08	accumulator L.P.assy	1		
39		HL438	095 024 28	accumulator H.P.assy	1		
40		HL438	095 243 78	piston	1		6.5kg
41		HL438	095 341 48	rotation bushing assy	1		4kg
42		HL438	095 342 78	front cover	1		
43		HL438	280 679 10	hose clamp	1		
44		HL438	442 638 80	hex.screw	6		
44		HL438	813 958 49	hex.screw	6		
45		HL438	522 077 80	o-ring	3		
46		HL438	522 143 70	o-ring	2		
47		HL438	522 149 30	o-ring	3		
48		HL438	800 323 69	adapter	2		
49		HL438	800 330 99	adapter	2		
50		HL438	800 347 99	gasket	2		
51		HL438	800 349 49	gasket	4		
52		HL438	800 658 09	o-ring	3		
53		HL438	801 319 29	spring pin	3		
54		HL438	801 590 69	valve	2		
55		HL438	808 010 69	o-ring	2		
56		HL438	808 747 79	o-ring	2		
57		HL438	808 757 89	u-seal	1		
58		HL438	808 769 49	plug	2		
59		HL438	811 037 39	bearing	1		
60		HL438	811 279 89	cap	3		
61		HL438	811 281 79	cap	2		
62		HL438	813 673 49	o-ring	1		
63		HL438	800 074 59	spiral pin	1		
		HL438		differing parts			
		HL438	099 508 98	drifter			
64		HL438	041 506 28	rubber seal	1		
65		HL438	090 094 48	flushing pipe assy	1		
65		HL438	090 383 98	flushing pipe assy	1		
66		HL438	090 124 08	adapter	1		
67		HL438	095 025 58	hydraulic motor	1		8.1kg
68		HL438	442 651 00	hex.screw	2		
		HL438	099 508 91	drifter			
64		HL438	041 506 28	rubber seal	1		
65		HL438	090 094 48	flushing pipe assy	1		
65		HL438	090 383 98	flushing pipe assy	1		
69		HL438	095 026 88	hydraulic motor	1		
70		HL438	442 221 70	hex.screw	2		
		HL438	099 508 92	drifter			
71		HL438	090 268 88	adapter	1		
72		HL438	090 319 98	flushing pipe assy	1		
72		HL438	090 425 18	flushing pipe assy	1		
73		HL438	085 369 58	rubber seal	1		

No	Crawler Drill	Drfter	Part Number	Part Name	Q'ty	Unit Price	Remarks
67		HL438	095 025 50	hydraulic motor	1		
68		HL438	442 651 00	hex.screw	2		
		HL438	099 508 93	drifter			
69		HL438	095 026 88	hydraulic motor	1		
70		HL438	442 221 70	hex.screw	2		
72		HL438	090 319 98	flushing pipe assy	1		
72		HL438	090 425 18	flushing pipe assy	1		
73		HL438	085 369 58	rubber seal	1		
		HL300	HL 300S R32	Shank Adaptor 7803-7549-01			HL300(400)R32

www.Drilling.kr